



#### MODEL 4755

Recommendations on fabric: thin natural/mixed suiting fabrics.

You will also need: fusible interfacing; dress zipper; decorative buckle.

Seam allowances: all seams 1 cm. Seam allowance along center and lower edge of skirt – 1.5 cm. Seam allowance for hem of garment – 1.5 cm.

**Note on seam allowances:** - If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise. - If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

**Note on length of fabric:** Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

#### CUTTING:

**Note on cutting:** On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric. When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold
2. Front skirt – cut 1 on fold
3. Fly piece – cut 1
4. Back facing – cut 1
5. Front facing – cut 1
6. Fly piece facing – cut 1

Fusible interfacing:

1. Back facing – cut 1
2. Front facing – cut 1

#### INSTRUCTIONS:

1. Apply fusible interfacing to facings.
2. Press lower seam allowance of fly piece facing onto wrong side. Pin facing to self piece right side to wrong side and sew. Fold facing onto right side and topstitch at fly piece along the fold.
3. Serge center and lower edges of fly piece, press onto wrong side and topstitch. Pin fly piece at front skirt, baste together along side edge.

## Nederdel – model 4755

4. Serge separately left side edges. Sew left side seam from notch for zipper to bottom, press seam apart, pressing the slit for zipper at the same time. Sew in zipper. Sew right side seam, press seam allowances towards back and serge.
5. Sew right side seam on facings, press seam apart. Serge lower edge. Pin facing to skirt right sides together and sew upper edge. Topstitch seam allowances onto facing at 0,2 cm from the seam. Fold facings onto wrong side, press. Sew seam allowances to zipper tape.
6. Serge lower edge of skirt, press onto wrong side and topstitch.
7. Sew on decorative buckle.

### TECHNICAL DRAWING:

