

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2034 Jacket with Pleated Peplum

Recommendations on fabric: thin natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 1 hook and eye.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance on lower edge of sleeve – 3 cm.

Main fabric:

1. Center upper back – cut 2
2. Side upper back – cut 2
3. Lower back – cut 1 on fold
4. Lower front – cut 2
5. Side upper front – cut 2
6. Center upper front – cut 2



7. Upper part center front facings – cut 2
8. Lower part center front facings – cut 2
9. Back neck facing – cut 1
10. Upper sleeve – cut 2
11. Lower sleeve – cut 2

Lining:

1. Center upper back – cut 2
2. Side upper back – cut 2
3. Lower back lining – cut 1
4. Lower front lining – cut 2
5. Upper front lining – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

Lining for back is cut using the pattern blocks for Shell, except for the width of neckline facing.

Fusible interfacing:

1. Upper part center front facings – cut 2
2. Lower part center front facings – cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing to the corresponding pieces, as well as to the seam allowances along the hem of the garment and the hem of the sleeves. Stabilize the edges of the armholes.
2. Sew the shoulder darts on the upper center back pieces and press the bulk toward the center. Sew the side backs to the center back and press the seams toward the center. Sew the center back seam and press it open.
3. Sew the side fronts to the front pieces and press the seams toward the center.
4. Sew the shoulder and side seams of the upper part of the jacket and press the seams open. Sew the side seams of the lower part of the jacket and press the seams open.
5. Sew the side seams of the lower lining and press the seams open. Sew the lower parts of the center front facings to the lining and press the seam allowances toward the center front facing.
6. Pin the lower part of the shell to the lining and sew the center front facings and lower

edge. Trim the corners, turn the piece right side out, straighten, and press. Make and baste the box pleats.

7. Sew the elbow seam on the sleeve and press it open. Press the sleeve hem. Sew and press open the front sleeve seam.

8. Sew the sleeves into the armholes, matching the notches and easing the fullness along the upper sleeve cap. Sew in the shoulder pads.

9. Sew the shoulder edges of the back neckline facing and the upper parts of the center front facings, and press the seams open. Place the center front facing onto the front with right sides together, pin, and sew around the center front facings and neckline. Clip the curves and trim the corners. Turn the piece right side out, straighten, and press.

10. Sew the lining of the upper part in the same way as the main fabric pieces, leaving an opening in the left elbow seam of the sleeve. Sew the lining to the inner edges of the button stands and to the back neckline facing.

11. Turn the center front facing and lining to the wrong side and sew them to the jacket, enclosing the lower part between the shell and the lining. Turn the jacket right side out through the sleeve opening. Sew the lining to the sleeve hem. Sew the opening closed.

12. Sew a hook and eye to the center front edge.

Congratulations, your jacket is ready! :)