

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2055 Jacket with Rounded Front Piece

Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; lining; shoulder pads; 2 buttons; 1 inner button.

### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of back – 4 cm, seam allowance on lower edge of sleeve – 3 cm.

### Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Collar – cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Upper sleeve – cut 2

## 7. Lower sleeve – cut 2

### Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Collar – cut 1

### Lining:

1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2

## INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible along the front lapel fold; its width should be 1 cm.
2. Sew darts on the back; press the bulk toward the center. Sew and press open the center back seam.
3. Sew darts on the front; press the bulk upward.
4. Sew and press open the shoulder seams of the jacket.
5. Pin the upper collar to the lower collar and sew the corners and fall. Start and stop stitching exactly at the marked seam line between the collar and garment. Clip curves and into the seam allowance near the notch. Turn the collar right side out, straighten, and press.
6. Sew and press open the shoulder seams of the back neckline facing and buttonstand.
7. Place the center front facing onto the front, right sides together. Pin and sew along the center front edge, sewing upward to the notch marking the end of the collar seam. Trim seam allowances at curves. Topstitch the seam allowance along the center front edge—onto the center front facing along the closure, and onto the front along the folded section. Place the stitch line 0.2 cm from the seam. Turn the buttonstands (center front edges) right side out, straighten the seams.
8. Sew the lower collar into the jacket neckline. Sew the upper collar into the neckline of the back facing and center front facing, clipping into the corner. Clip into the

seam allowances of the collar, press open, and slipstitch close to the seam.

9. Fold the already sewn-down center front facing near the side seam and sew the side seams. Press the back seam allowance upward.
10. Sew the elbow seam on the sleeve and press the seam open. Press the hem seam allowance. Sew the front seam on the sleeve and press open. Sew the sleeves into the armholes. Press the seams.
11. Sew the lining, leaving an opening in the left elbow seam. Sew the lining to the back neckline facing, center front facing, and hem of the back. Sew the lining to the sleeve hem. Turn the jacket right side out through the opening. Sew the opening closed.
12. Make buttonholes and sew on the buttons. Sew on the inner button.

Congratulations, your jacket is ready! :)