

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2064 High collar blouse with puffed sleeves

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, 9 buttons.

### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm.

### Main fabric:

1. Back – cut 1 on fold
2. Front - cut 1
3. Slit facing – cut 1
4. Stand collar – cut 2
5. Sleeve – cut 2
6. Cuff – cut 4

### Fusible interfacing:

1. Slit facing – cut 1
2. Stand collar – cut 1
3. Cuff – cut 2



## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge the outer edge of slit facing. Pin facing onto front right sides together and sew with two parallel stitch lines at 0.5 cm on the right and on the left from the slit. Slash front and facing along the slit line. Make diagonal cuts at 1-1.5 cm from the end of the stitch lines. Turn facing onto the wrong side through the resulting opening, straighten edges. Sew a fixing stitch at the corner from the wrong side.
3. Make and stitch a pleat on front from the wrong side at 1.5 – 2.0 cm according to markings.
4. Sew front darts, press bulk towards top.
5. Sew shoulder and side seams, press seams towards back and serge.
6. Pin together parts of stand collar right sides together inside and sew along outer edge and ends, start, and stop stitching exactly at the seam line of collar stand. Clip into curves, trim away corners, turn right side out stand collar onto right side, press. Sew the outer stand collar into neckline, fold inside open edge of internal stand collar and stitch in the ditch.
7. Sew a gathering stitch along upper part of sleeve cap and gather fullness. Sew a gathering stitch along lower edge of sleeve and gather fullness. Sew sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge, and press.
8. Pin cuffs together, right sides together and sew side and lower edges. Start and stop stitching exactly at the marked seam line cuffs. Turn the piece right side out, press. Sew the outer side of cuff to sleeve, turn seam allowance of inner cuff under and stitch-in-the ditch into seam of outer cuff.
9. Press lower edge of garment onto wrong side two times at 1 cm and topstitch.
10. Make buttonholes on stand collar, placket, and cuffs. Sew on buttons.

Congratulations, your blouse is ready! :)