

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2072 Loose asymmetrical dress

Recommendations on fabric: Natural/mixed fabric suitable for dresses approx. 1.6 m (sizes 32–40), approx. 1.8 m (sizes 42–54) with a fabric width of 150 cm.

You will also need: Fusible interfacing; 6 buttons.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm; seam allowance for hem of garment – 2 cm; seam allowance for hem of sleeve – 1.2 cm.

Main fabric:

1. Back – 1 piece on fold
2. Right Center Front – 1 piece
3. Left Center Front – 1 piece
4. Right Side Front – 1 piece
5. Left Side Front – 1 piece
6. Lower Front – 1 piece
7. Placket – 1 piece



8. Sleeve – 2 pieces
9. Back Neck Facing – 1 piece
10. Right Front Neck Facing – 1 piece
11. Left Center Front Facing – 1 piece

Fusible interfacing:

1. Placket – 1 piece
2. Back Neck Facing – 1 piece
3. Right Front Neck Facing – 1 piece
4. Left Center Front Facing – 1 piece

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on the back, press the bulk towards the center.
3. Sew princess seams on the left and right front (attach side parts to center parts), press towards the center and serge.
4. Sew shoulder seams, press the seam allowances towards the back and serge.
5. Sew the right front neckline facing and the center front facing to the back neckline facing. Press seam allowances open and serge the outer edge. Pin the facings to the garment, right sides together, and sew the neckline and the left center front edge. Clip into the curves and trim the corner.
6. Fold the placket half lengthwise, right sides together, and sew the upper corner. Turn the right side out, straighten, and press. Sew the outer side to the right front, turn under the seam allowance of the inner side, and stitch in the ditch.
7. Place the right front over the left front and baste together along the lower edge.
8. Make a box pleat on the lower front. Sew the upper front to the lower front, press the seam allowance downwards, and serge.
9. Sew side seams, press the seam allowances towards the back, and serge.
10. Serge the lower edge of the sleeve, press to the wrong side, and topstitch. Sew the sleeve seams, press towards the back, and serge. Set in the sleeves, matching notches and

easing as necessary. Serge and press.

11. Serge the bottom edge of the garment, press to the wrong side, and topstitch.

12. Make buttonholes on the placket. Sew buttons onto the left front.

Congratulations, your dress is ready! :)