

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2092 Blouse layer-on-layer with yoke

Recommendations on fabric: natural/mixed fabrics suitable for blouses; companion fabric - chiffon.

You will also need: fusible interfacing; 4 buttons.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 1.5 cm; other seams – 1 cm.

### Main fabric:

1. Inner back - cut 1 on fold
2. Inner front - cut 1 on fold
3. Front inset – cut 2
4. Back yoke – cut 1 on fold
5. Placket – cut 4
6. Sleeve – cut 2
7. Sleeve decorative tab – cut 2



Chiffon:

1. Outer back - cut 1 on fold
2. Outer front - cut 1 on fold

Fusible interfacing:

1. Placket – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Make pleats on outer back, fold bulk towards center. Pin outer back onto inner back, wrong side onto right side and baste together along upper edge. Sew back yoke to yoke, press seam allowances towards yoke and serge.
3. Pin plackets together by two and sew outer edge. Turn pieces right side out straighten and press. Make buttonholes on right placket. Sew plackets to front inset, press seam allowances towards inset and serge. Pin right inset onto left inset and baste together along lower edge.
4. Make pleats on outer front, fold bulk towards center. Pin outer front onto inner front, wrong side onto right side and baste together along upper edge. Sew inset to front, press towards front and serge.
5. Sew shoulder seams, press seams towards back and serge. Sew side edges on inner and outer pieces separately, press seams towards back and serge. Baste together along the armhole edge, treat as one piece in the future.
6. Cut (or take ready) a bias tape, its length should equal the length of the neckline + 4 cm. Fold bias tape in half lengthwise right side out and press. Unfold the piece, press edges towards the fold. Sew bias tape to neckline (pin bias tape to neckline edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line).
7. Fold decorative tabs in half lengthwise right sides together and sew along longer and one shorter edge. Turn right side out, slashing seam allowances in corners, straighten and press. Serge raw shorter edge. Topstitch decorative tabs according to the markings onto the wrong side of sleeves.
8. Sew sleeve seams, press towards back and serge. Sew sleeves into armholes, serge, and press.

9. Serge hem of garment and hem of sleeve, turn inside and topstitch.

10. Sew on the buttons on the left placket. Make buttonholes on decorative tabs, sew on buttons onto sleeves.

Congratulations, your blouse is ready! :)