

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2158 Wrap Dress with Ruffles and Long Sleeves

Recommendations on fabric: well draping natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; 4 buttons.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 1.2 cm.

### Main fabric:

1. Upper back – cut 1 on fold
2. Lower back – cut 1 on fold
3. Back flounce – cut 1 on fold
4. Upper front – cut 2
5. Lower front – cut 2
6. Front flounce – cut 2
7. Sleeve – cut 2
8. Cuff – cut 2



## 9. Belt – cut 1

### Fusible interfacing:

#### 1. Cuff – cut 2

### INSTRUCTIONS:

1. Apply fusible interfacing to the cuffs and to the one-piece upper back facing.
2. Cut (or use ready-made) bias tape with a width of 4 cm and a length equal to the back neckline + 4 cm. Fold the bias tape in half lengthwise, right sides out, and press. Pin the bias tape to the back neckline from the right side, leaving loose ends, and sew. Fold the bias tape to the wrong side, clip into seam allowances, and topstitch onto the main piece along the seam. Press the seam.
3. Serge the edge of the one-piece center front facing on the upper front. Sew a gathering stitch along the upper edge of the upper front and gather the fullness. Sew the shoulder seams, placing the Back between the Front and the Center Front Facing. Press the seams toward the back and serge. Turn the center front facing to the wrong side, straighten, and press. Baste to the main piece along the lower edge.
4. Sew a gathering stitch along the lower edge of the Upper Back and gather fullness. Sew the Upper Back to the Lower Back, press the seam toward the top, and serge. Sew the back flounce to the Lower Back, press the seam toward the top, and serge.
5. Sew a gathering stitch along the lower edge of the Upper Front and gather fullness. Sew the Upper Front to the Lower Front, press the seam toward the top, and serge. Sew the front flounce to the Lower Front, press the seam toward the top, and serge.
6. Cut a slit on the sleeve along the marked line. Cut bias tape from the main fabric (or use ready-made), with a width of 4 cm and a length equal to twice the slit length + 4 cm. Fold the bias tape in half lengthwise and press. Press the outer seam allowances toward the center. Sew the bias tape to the sleeve slit (pin the bias tape to the slit edge from the right side and sew; fold the bias tape to the wrong side and topstitch along the fold line).
7. Sew a gathering stitch along the sleeve cap and gather fullness. Sew the sleeve into the open armhole, serge, and press.
8. Sew the side seams, processing the sleeve seam at the same time. Press the seams toward the back and serge.

9. Sew a gathering stitch along the lower edge of the sleeve and gather fullness. Fold the cuff in half lengthwise, right sides together, and sew the short sides. Start stitching exactly at the line marking the seam between the cuff and the sleeve. Turn the cuff right side out and press. Sew the outer side of the cuff to the lower edge of the sleeve, fold the inner side of the cuff inward, and stitch in the ditch.
10. Serge the bottom edge of the garment, press to the wrong side, and topstitch.
11. Make buttonholes on the front. Sew on the inner and outer buttons. Make buttonholes and sew on buttons on the cuffs.
12. Fold the belt in half lengthwise, right sides together, and sew, leaving an opening along the lower edge for turning. Turn the belt right side out, straighten, and press. Sew the opening closed by hand.

Congratulations, your dress is ready! :)