

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2189 Relaxed Blouse with Yoke and Batwing Sleeves

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: 1 button; fusible interfacing.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: seam allowance for hem of garment – 2 cm; other seams – 1 cm.

Main fabric:

1. Back yoke – cut 2
2. Back – cut 1 on fold
3. Front – cut 1 on fold
4. Front yoke – cut 1 on fold
5. Cuff – cut 2

Fusible interfacing:

1. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing to the cuffs.
2. Make and baste pleats along the upper edge of the front, folding bulk towards the center. Sew the front yoke to the front. Press upwards and serge.
3. Serge the center edges of the back yoke. Press to the wrong side and topstitch. Sew the back yokes to the back, serge seams, and press upwards.
4. Sew the right shoulder seam, including the sleeve seam at the same time. Serge and press towards the back.
5. Cut (or prepare) bias tape 2.5 cm wide and 5 cm long for the loop buttonhole. Fold the tape in half lengthwise, right sides together, and stitch 0.3 cm from the fold. Trim seam allowances close to the seam, turn the tape right side out, and straighten into a rolled hem. Adjust the loop length. Sew the button loop to the yoke.
6. Cut (or prepare) bias tape 4 cm wide and as long as the neckline plus 4 cm. Fold the bias tape in half lengthwise, right side out, and press. Pin the bias tape to the neckline from the right side, leaving loose ends, and stitch. Fold the bias tape to the wrong side, clip seam allowances, and topstitch onto the main piece along the seam. Press the seam.
7. Sew the side and left shoulder seams, including the sleeve seam at the same time. Serge and press towards the back.
8. Sew the cuff into a ring, press seams open. Fold the cuff in half lengthwise and press. Sew the outer side of the cuff to the sleeve. Turn under the seam allowance of the inner side and stitch in the ditch.
9. Serge the lower edge of the garment, turn to the wrong side, and topstitch.
10. Sew a button to the yoke.

Congratulations – your blouse are finished! :)