

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2193 Blouse with Tie Sleeves

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, 3 buttons.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: seam allowance for hem of garment – 2 cm, other seams – 1 cm.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Sleeve – cut 2
4. Cuff – cut 4
5. Center front facing – cut 2
6. Back neck facing – cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew waist tucks on the fronts and backs.
3. Sew the center back seam, press to the left, and serge.
4. Sew side and shoulder seams, press towards the back, and serge.
5. Sew and press open the shoulder seams of the back neckline facing and buttonstand. Serge the outer edge.
6. Place the center front facing onto the front, right sides together, pin, and sew the lower corner, center front edge, and neckline. Turn buttonstands (center front edges) right side out and straighten seams.
7. Cut a slit on the sleeve along the marked line. Cut bias tape from the main fabric (or use ready-made) 4 cm wide and as long as twice the slit length plus 4 cm. Fold the bias tape in half lengthwise and press. Press the outer seam allowances towards the center. Sew the bias tape to the sleeve slit (pin bias tape to slit edge from the right side and stitch, fold bias tape to the wrong side, and topstitch along the fold line).
8. Sew the sleeve seam, press towards the back, and serge. Insert the sleeves into the armholes, matching notches. Serge and press.
9. Pin cuffs together, right sides facing, and sew the lower and upper edges from corner to mark. Trim corners and clip seam allowances near the notch. Turn the cuff right side out, straighten, and press. Sew a gathering stitch along the lower edge of the sleeve and gather fullness. Sew the outer cuff to the lower edge of the sleeve. Fold inside the inner cuff and stitch in the ditch.
10. Serge the lower edge of the garment, press to the wrong side, and topstitch.
11. Make buttonholes on the right front and sew buttons on the left front.

Congratulations – your blouse are finished! :)