

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2197 Long Jacket with Diagonal Front Edge

Recommendations on fabric: natural/mixed suiting fabric

You will also need: fusible interfacing; lining; 3 buttons; 1 inner button; shoulder pads, sleeve heads.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3 cm.

Main fabric:

1. Back – cut 2
2. Center right front – cut 1
3. Center left front – cut 1
4. Side front – cut 2
5. Sleeve – cut 2
6. Back neck facing – cut 1

7. Center front facing left – cut 1
8. Center front facing right – cut 1

Fusible interfacing: back neck facing, center front facing right, center front facing left.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on the back, pressing bulk towards the center. Sew the center back seam, serge, and press to the left.
3. Sew side fronts to the center front, serge seams, and press towards the center.
4. Sew the shoulder and side seams of the dress, serge, and press towards the back.
5. Sew the sleeve seam, serge, and press towards the back. Insert sleeves into armholes, matching notches. Attach shoulder pads and sleeve heads.
6. Sew and press open the shoulder seams of the back neckline facing and buttonstand. Serge the outer edge.
7. Place the center front facing onto the front, right sides together, pin, and sew along the center front, lower edge, and neckline. Clip seam allowances and trim corners. Turn the facings to the wrong side and press.
8. Serge hem allowances of the dress and sleeves, fold to the wrong side, and topstitch or finish as desired.
9. Make buttonholes on the right front and sew buttons on the left front. Make an inner buttonhole on the left front and attach the inner button.

Congratulations – your jacket are finished! :)