

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2212 Dress with Raglan Sleeves and High V-Slit Neckline

Recommendations on fabric: natural/mixed knit fabric of small stretchiness.

You will also need: knit fusible interfacing; 1 dress zipper.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Back sleeve – cut 2
6. Front sleeve – cut 2
7. Back neck facing – cut 2



8. Front neck facing – cut 2

Fusible interfacing:

1. Back neck facing – cut 2
2. Front neck facing – cut 2

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Apply interfacing to the facings.
2. Sew side backs to the center back, press towards the center, and serge. Sew side fronts to the front, press towards the center, and serge.
3. Serge the center back edges separately. Sew the center back seam from the zipper notch to the hem. Press seam allowances open, pressing the slit for the closure at the same time. Insert the zipper.
4. Sew the center front seam from the notch to the hem, press seam open, and serge.
5. Sew back sleeves to the back, press seam allowances towards the sleeve, and serge. Sew front sleeves to the front, press seam allowances towards the sleeve, and serge.
6. Sew the upper sleeve edges, press seams towards the back, and serge. Sew the lower sleeve edges and side seams continuously, press towards the back, and serge.
7. Sew shoulder seams and the front center seam of the facings from the notch to the hem, press seams open, and serge the lower edge. Pin the facing to the garment, right sides together, and sew the neckline and front slit. Clip curves, trim corners, turn the facing to the wrong side, straighten, and press. Slipstitch the facing to the zipper tape and shoulder seams.
8. Serge hem allowances of the garment and sleeves, press to the wrong side, and topstitch.

Congratulations – your dress are finished! :)