

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2214 Dress with chiffon sleeves

Recommendations on fabric:
natural/mixed fabric suitable for dresses. Chiffon in matching color.
You will also need: fusible interfacing;
dress zipper, 2 buttons.

CUTTING:

The word, "beam" used on some patterns means "straight of grain".
Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Back neck facing - cut 2
6. Front neck facing - cut 1
7. Cuff – cut 2

Chiffon:

1. Sleeve – cut 2
2. Tie – cut 1

Fusible interfacing:

1. Back neck facing - cut 2
2. Front neck facing - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, press towards center and serge. Sew side fronts to front, press towards center and serge.
3. Serge separately center back edges. Sew center back seam from notch for zipper to bottom, press seam apart. Sew in zipper.
4. Sew center seam on front, press towards left and serge.
5. Sew side and shoulder seams, press seams towards back and serge.
6. Serge tie along three edges, press seam allowances onto wrong side and topstitch. You may also finish the edges with thin rolled hem. Fold piece in half lengthwise, make a pleat as desired and topstitch onto the neckline edge between the markers.
7. Sew shoulder seams of neck facings, press seam apart. Serge outer edge. Pin facings to garment right sides together and sew the neckline. Clip into curves, turn pieces right side out. Slipstitch facing to garment along the shoulder edges, center front seam and zipper tape.
8. Cut slit on sleeve along the marked line. Cut bias tape from main fabric (or take ready), its width should equal 4 cm and length should equal two lengths of slit +4 cm. Fold bias tape in half lengthwise and press. Press outer seam allowances towards center. Sew bias tape to slit of sleeve (pin bias tape to slit edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line).
9. Sew sleeve seam, press seams towards back and serge. Sew a gathering stitch along the upper edge of the sleeve cap and gather fullness. Sew sleeves into armholes, matching notches. Serge and press.

10. Fold cuff in half lengthwise, right sides together and sew short sides. Start stitching exactly at the line which marks the seam between cuff and sleeve. Trim away corners, turn cuff right side out, straighten, press. Sew a gathering stitch along lower edge of sleeve and gather fullness. Sew outer side of cuff to lower edge of sleeve. Fold inside inner side of cuff inside and stitch in the ditch.

11. Serge lower edge of garment, press onto wrong side and topstitch or hem as desired.

12. Make buttonholes on cuffs, sew on buttons.

Congratulations, your dress is ready! :)