

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2225 T-Shirt with Round Yoke

Recommendations on fabric: well draping natural/mixed knit fabric of medium stretchiness.

You will also need: 3 buttons, knit fusible interfacing.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: seam allowance for hem of garment and hem of sleeve – 2 cm, other seams – 1 cm.

Main fabric:

1. Front – cut 1 on fold
2. Back – cut 1 on fold
3. Back yoke – cut 2
4. Front yoke – cut 4
5. Sleeve – cut 2
6. Placket – cut 2



Fusible interfacing:

1. Back yoke – cut 1
2. Front yoke – cut 2
3. Placket – cut 2

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Sew the outer back yoke to the back, press towards the facing.
2. Sew a gathering stitch along the upper edge of the front from the marking to the center edge and gather fullness. Press the outer front yoke towards the front. Press seam allowances towards the facing.
3. Sew shoulder seams of the blouse, serge, and press towards the back.
4. Sew upper corners of the plackets. Turn the plackets right side out and press. Sew the plackets to the right side of the front along the longer edge, stopping 1 cm from the bottom. Serge. Clip into the seam allowance on the front, leaving 1 mm to the stitch line. Thread the ends of the plackets inside, align them so that their edges meet exactly line to line, and stitch, fastening the lower edge. Serge the lower edge.
5. Sew the shoulder seams of the inside yokes, press seams open, and serge the outer edge of the inner yoke.
6. Pin the yokes right sides together and sew along the neckline edge and center front edge, placing the placket between the yokes. Clip seam allowances, turn the inner yoke to the wrong side, and press. Slipstitch the inner yoke into the seam of the outer yoke or stitch in the ditch.
7. Sew side seams, press towards the back, and serge. Sew sleeve seams, serge, and press towards the back. Insert sleeves into armholes and serge.
8. Serge the hem of the garment and sleeve hems, press to the wrong side, and topstitch.
9. Make buttonholes on the right placket. Sew buttons on the left placket.

Congratulations – your t-shirt are finished! :)