

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2239 T-Shirt with Faux Closure

Recommendations on fabric: natural/mixed knit fabrics of high to medium stretchiness.

You will also need: knit fusible interfacing; 6 buttons.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: seam allowance for hem of garment and hem of sleeve – 1.5 cm, other seams – 1 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 1 on fold
3. Sleeve – cut 2
4. Placket – cut 2
5. Decorative Tab – cut 2
6. Stand collar – cut 2

Fusible interfacing:

1. Stand collar – cut 1
2. Placket – cut 1

INSTRUCTIONS:

Advice: sew knit pieces with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances to 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

1. Apply fusible interfacing.
2. Pin the plackets right sides together and sew the opening. Trim the corner, turn right side out, and press.
3. Place the placket onto the front, both right sides facing up, and stitch. Clip into the corners on the front. Fold the placket to the wrong side, straighten, serge, and press.
4. Sew side and shoulder seams, press towards the back, and serge.
5. Pin the outer and inner stand collars right sides together and sew along the outer edges, starting and stopping exactly at the marked seam line. Clip curves, turn the finished stand collar right side out, and press.
6. Sew the outer stand collar to the neckline, fold under the raw edge of the inner stand collar, and stitch in the ditch.
7. Fold the decorative tab in half lengthwise, right sides together, and sew along one short and one long edge. Trim seam allowances, turn the tab right side out, and press. Make buttonholes on the decorative tabs.
8. Sew the sleeve seam, press towards the back, and serge. Pin the decorative tab, right side down, to the wrong side of the sleeve and topstitch according to markings.
9. Serge the hem of the garment and the sleeve edges, press to the wrong side, and topstitch.
10. Sew buttons onto the placket and sleeves.

Congratulations – your t-shirt are finished! :)