

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2241 Short Jacket with Pockets

Recommendations on fabric: natural/mixed suiting or light coat fabrics.

You will also need: lining; fusible interfacing; separating zipper; shoulder pads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: upper seam allowance of pocket – 2 cm. All other seams 1 cm.

Main fabric:

1. Front – cut 2
2. Back – cut 1 on fold
3. Sleeve – cut 2
4. Pocket – cut 2
5. Flap – cut 4
6. Center front facing – cut 2
7. Back neck facing – cut 1
8. Collar – cut 2

9. Hem facing – cut 1 on fold
10. Cuff – cut 2

Lining:

1. Front – cut 2
2. Back – cut 1 on fold
3. Sleeve – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Collar – cut 1
3. Back neck facing – cut 1
4. Cuff – cut 2
5. Flap – cut 2
6. Hem facing – cut 1

Attention: front and back from lining are cut using the pattern clocks for the main fabric except for the width of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge the upper edge of the pocket. Fold the seam allowance to the inside and topstitch. Serge and fold in the lower and side seam allowances of the pocket to the wrong side and press. Mark the pocket placement on the front and topstitch the pocket in place. Pin the flaps right sides together and sew along the side and lower edges. Trim seam allowances, turn right side out, and press. Sew a decorative stitch along all edges of the flap. Pin the flap to the front according to markings, with seam allowance directed downwards, and topstitch. Fold the flap down and sew a securing stitch.
3. Sew shoulder and side seams, press seams open.
4. Sew sleeve seam, press towards the back. Insert the sleeve into the armhole, press seam allowance, and sew in shoulder pads. Sew the cuff into a ring, press seam open. Fold the cuff in half lengthwise, right side out, and press. Sew the outer side of the cuff to the sleeve.
5. Sew the lower collar into the neckline. Clip seam allowances and press open.

6. Sew the lower placket to the jacket, press seam open.
7. Sew the zipper to the jacket.
8. Sew seams on the lining, leaving an opening in the left sleeve.
9. Sew the shoulder seams of the facings and the center front facings, press seams open. Sew the upper collar into the neckline, clip seam allowances, and press open. Sew the facing and center front facing to the lining, pressing seam allowances towards the lining. Sew the lining to the inner edge of the lower facing, press towards the facing.
10. Pin the lining to the garment, right sides together. Sew the center front facings and collar. Trim seam allowances at collar corners. Turn the jacket right side out through the opening. Slipstitch the collars together close to the seam. Stitch in the ditch along the seam of the lower placket, connecting the main fabric to the lining.
11. Sew the lining to the cuff. Slipstitch the seam allowances of the main fabric and lining together.
12. Sew the opening closed.
13. Sew a decorative stitch along the center front edge and around all edges of the collar.

Congratulations – your jacket are finished! :)