

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2243 Asymmetric Blazer with Slanted Edge

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; 3 buttons; shoulder pads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm. Seam allowance for hem of sleeve – 3 cm.

Main fabric:

1. Center back – cut 2
2. Side left back – cut 1
3. Side right back – cut 1
4. Center left front – cut 1
5. Center right front – cut 1
6. Side left front – cut 1
7. Side right front – cut 1
8. Lower collar – cut 1
9. Upper collar – cut 1
10. Right center front facing – cut 1
11. Left center front facing – cut 1
12. Back neck facing – cut 1

13. Sleeve – cut 2
14. Pocket frame – cut 2
15. Flap – cut 4

Attention: lining for front and back is cut using the pattern blocks for main fabric except for the width of the center front facing and back neckline facing.

Lining:

1. Center back – cut 2
2. Side left back – cut 1
3. Side right back – cut 1
4. Center left front – cut 1
5. Center right front – cut 1
6. Side left front – cut 1
7. Side right front – cut 1
8. Sleeve – cut 2
9. Smaller pocket bag – cut 2
10. Bigger pocket bag – cut 2

Fusible interfacing:

1. Center left front – cut 1
2. Center right front – cut 1
3. Left center front facing – cut 1
4. Right center front facing – cut 1
5. Back neck facing – cut 1
6. Upper collar – cut 1
7. Flap – cut 2
8. Pocket frame – cut 2

Attention: pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

INSTRUCTIONS:

1. Apply fusible interfacing. Apply a strip of interfacing 1 cm wide along the fold line of the lapels on the fronts.
2. Sew the center back seam, serge, and press open. Sew side backs to the center back, press towards the center.
3. Sew side fronts to the center front, press towards the center.

4. Sew flaps pairwise, right sides together, along the side and lower edges. Trim seam allowances, cut corners, turn right side out, and press. Mark the pocket position with parallel lines. Fold the pocket frame in half, wrong sides together, and press. Mark additional lines on the pocket frame and flap for stitching parallel to the fold. Sew the larger pocket bag to the pocket flap. Sew the pocket frame and flap to the front. Slash the front along the marked line on the pattern. Snip diagonally towards the end of the stitching, 1–1.5 cm from the end of the pocket opening. Turn the pocket frame and flap to the wrong side through the opening, straighten edges. Secure pocket corners with double stitching from the wrong side at the corners. Sew the smaller pocket bag into the seam of the pocket frame. Sew together the pocket bag edges and serge.
5. Sew shoulder and side seams, press open.
6. Pin the upper collar to the lower collar and sew the corners and fall, starting and stopping exactly at the marked collar seam line. Trim corners and clip seam allowances near the notch. Turn the collar right side out, straighten, and press.
7. Sew and press open the shoulder seams of the back neckline facing and buttonstand.
8. Place the center front facing onto the front, right sides together, pin, and sew along the center front edge up to the notch marking the end of the collar seam.
9. Sew the lower collar to the jacket neckline, sew the upper collar to the neckline of the back facing and center front facing. Press collar seam allowances open and slipstitch close to the seam.
10. Sew the sleeve seam, press towards the back. Insert sleeves into the armholes, matching notches and easing along the sleeve cap. Attach shoulder pads.
11. Press the hem of the sleeves and jacket to the wrong side.
12. Sew lining seams, leaving an opening in the left sleeve. Sew the lining to the buttonstands and facing. Attach the lining to the hem of the jacket and the sleeve hems.
13. Turn the jacket right side out through the opening. Sew the opening closed.
14. Make buttonholes and sew on buttons.
Congratulations – your blazer are finished! :)