

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2254 Blazer with Decorative Darts

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 1 button.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3.5 cm.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Center front facing – cut 2
6. Back neck facing – cut 1
7. Upper sleeve – cut 2

8. Lower sleeve – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Attention: center back and center front from lining are cut using pattern blocks for self fabric except for the width of back neckline facing and center front facing correspondingly.

Fusible interfacing:

1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Cut a strip of fusible interfacing and apply it along the back neckline edge. Apply fusible interfacing to the lower edge of the garment and to the sleeve hems.
2. Sew the dart on the center back, press bulk towards the center, and sew a decorative stitch 0.1 cm from the seam. Serge separately, sew, and press open the princess seams on the back (attach side backs to center backs). Sew and press open the center back seam.
3. Sew the dart from the shoulder edge on the center front. Press bulk towards the center, and sew a decorative stitch 0.1 cm from the seam. Fold the center front with wrong sides together and stitch the horizontal darts, pressing bulk downwards. Sew the princess seam on the front and press the seam open.
4. Sew and press open the shoulder and side seams.
5. Sew the side seams of the back neckline facing and buttonstands, press seams open. Pin the center front facings to the garment and sew the center edges and neckline with one continuous seam. Trim seam allowances, clip curves, turn the garment right side out, and press. Topstitch the seam allowance on the buttonstand onto the buttonstand, placing the stitch line 0.2 cm from the seam. Press the lower edge of the

garment.

6. Sew the elbow seam of the sleeve, press it open, adjusting ease on the upper part of the sleeve and matching notches. Press the sleeve hem. Fold up the seam allowance at the hem, sew, and press open the front sleeve seam.
7. Sew the sleeves into the armholes, matching notches and easing the sleeve cap. Attach shoulder pads.
8. Sew the lining seams and insert the sleeves, leaving an opening for turning in the left elbow seam. Sew the lining to the inner edges of the center front facings and facing.
9. Sew the lining to the lower edge of the garment and the sleeve hems. Turn the jacket right side out. Sew the opening closed.
10. Make a button loop on the right front and sew a button on the left front.

Congratulations – your blazer are finished! :)