

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2274 Blouse with Flutter Sleeves and V-Neckline

Recommendations on fabric: natural/mixed fabrics suitable for blouses. Lace fabric for decoration.

You will also need: fusible interfacing.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 1.2 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 1
3. Placket – cut 2
4. Stand collar – cut 2
5. Sleeve – cut 2

Main fabric 1:

1. Back yoke – cut 1

2. Front yoke – cut 2

Fusible interfacing:

1. Placket – cut 2
2. Stand collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Make and baste a box pleat on back. Sew yoke to back, press seam allowances towards yoke and serge. Sew yokes to front, press seam allowances towards yokes and serge.
3. Press plackets in half lengthwise, right side out. Sew plackets to front along the longer edge, leaving a distance of 1 cm from hem. Clip into seam allowance on front, leaving 1 mm to the stitch line. Make a pleat on front, placing right placket over left placket. Sew ends of plackets together, folding away the front and securing the lower edge. Serge.
4. Sew shoulder and side seams, press seams towards back and serge.
5. Pin stand collar pieces together, right sides together, and sew along the outer edge, starting and stopping exactly at the seam line of the collar stand. Turn the stand collar right side out and press.
6. Sew outer stand collar into neckline, fold inside the raw edge of inner stand collar and stitch in the ditch.
7. Sew sleeve seam, serge and press. Serge lower edge of sleeve, press onto wrong side and topstitch. You may also finish the sleeve hem with a narrow rolled hem. Sew sleeves into armholes, serge and press.
8. Serge lower edge of garment, press onto wrong side and topstitch.

Congratulations – your blouse are finished! :)