

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2306 Denim dress

Recommendations on fabric:  
natural/mixed jeans fabrics.

You will also need: fusible  
interfacing; 10 buttons

### CUTTING:

The word, "beam" used on some  
patterns means "straight of grain".  
Some pieces will be cut on the fold,  
this is noted on the pattern piece.

Mark all notches and other design  
features such as darts, pleats etc. from the pattern onto your fabric.



### Main fabric:

1. Back yoke - cut 1
2. Back - cut 2
3. Front - cut 2
4. Front yoke - cut 2
5. Sleeve – cut 2
6. Collar – cut 2
7. Stand collar – cut 2
8. Cuff – cut 2
9. Pocket – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Stand collar – cut 1
3. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to the one-piece plackets on front and to the seam allowances along the upper edges of pockets.
2. Sew darts on back and front. Press bulk of waist darts towards center, press bulk of bust darts towards top. Topstitch darts at 0.1 cm from seam.
3. Sew center back seam, press towards left and serge. Sew a decorative stitch at 0.1 cm from seam. Sew yoke to back, press towards top and serge. Sew a decorative stitch at 0.1 cm from seam.
4. Sew front yoke to front, press seam allowances towards yoke and serge. Sew a decorative stitch at 0.1 cm from seam.
5. Serge upper seam allowance of pocket, press onto wrong side and topstitch. Press side and lower seam allowances of pocket onto wrong side. Pin pockets onto front according to markings and topstitch.
6. Fold the one-piece placket onto wrong side and press. Fold under the seam allowance of the inner edge of placket and topstitch onto front along the fold. Sew a decorative stitch at 0.1 cm from edge plackets.
7. Sew shoulder seams, press seams towards back and serge.
8. Pin upper collar to lower collar, right sides together. Sew ends of collar and collar fall. Trim seam allowances. Turn the collar right side out, straighten and press. Sew a decorative stitch at 0.1 cm from edge. Pin stand collars together, right sides together, put ready collar between them, adjust notches and sew, sewing ends of stand collar at the same time. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Turn finished collar right side out and press. Sew upper stand collar with collar into neckline, fold raw edge of lower stand collar and stitch-in-the-ditch along seam of upper stand collar.
9. Serge lower edge of garment, press onto wrong side and topstitch.

10. Sew side seams, press seams towards back and serge.

11. Sew sleeve seam, serge, and press. Sew cuff into ring, press seam apart. Fold cuff in half lengthwise, right sides together and press. Sew outer side of cuff to sleeve. Fold under the seam allowance of the inner side inside and stitch in the ditch.

12. Sew sleeves into armholes, serge, and press.

13. Make buttonholes on right placket, sew on buttons on the left one. Make button loop and sew on button on stand collar.

Congratulations, your dress is ready! :)