

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guide lines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2311 Sarafan With Pockets

Recommendations on fabric:
natural/mixed fabric suitable for dresses, natural/mixed suiting fabrics.

You will also need: fusible interfacing; buckle; 2 buttons for jeans; elastic tape, its width should equal 1.5 cm.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Back – cut 2
2. Front - cut 1 on fold
3. Strap – cut 2
4. Front facing - cut 1 on fold
5. Back facing – cut 2
6. Pocket – cut 1

Fusible interfacing:

1. Front facing - cut 1 on fold
2. Back facing – cut 2
3. Strap – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge upper seam allowance of pocket, press onto wrong side and topstitch. Press side and lower seam allowances of pocket onto wrong side. Pin pocket onto front according to markings and topstitch.
3. Sew center back seam. Press seam apart.
4. Sew side seams. Serge and press apart.
5. Fold strap in half lengthwise right sides together and Sew along the front and the long edge. Trim seam allowances, turn right side out and press.
6. Sew center seam on back facings. Press seam apart. Sew side edges on front facings and back facings. Press seam apart. Serge lower edge facings.
7. Pin facings onto front and back, right sides together, insert straps and sew the upper edge. Trim seam allowances, trim corners and fold onto wrong side.
8. Between notches sew a stitch at 2 cm from edge, making a casing. Thread elastic tape into casing and fasten it.

Congratulations, your sarafan is ready! :)