

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2318 Jumpsuit with pockets and button closure

Recommendations on fabric: natural/mixed silk fabrics.

You will also need: fusible interfacing, elastic tape 0.7 cm wide, 3 buttons.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: seam allowance along the upper edge of the front shorts and the back shorts, as well as along the lower edge of back and of front – 2 cm. Seam allowance along the lower edge of the front halves and the back halves – 2 cm. Other seams – 1 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Front half – cut 2
4. Back half – cut 2
5. Side – cut 2

6. Pocket bag – cut 2
7. Center front facing – cut 2
8. Back neck facing – cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to the pocket opening seam allowances on the front shorts pieces.
2. Pin the pocket bag to the front piece and sew the pocket opening. Turn the pocket bag to the wrong side, understitch the seam allowances to the pocket bag 0.1 cm from the seam, and press.
3. Pin the front piece to the side piece according to the markings. Sew the pocket bag to the side piece and serge the seam. Baste the pocket bag to the front piece along the upper and side edges.
4. Sew the center seams of the back shorts pieces and front shorts pieces. Press the seam allowances open and serge. Sew the side seams of the shorts, press the seam allowances toward the back, and serge. Sew the inseam, press the seam allowances toward the back, and serge.
5. Sew the shoulder and side seams of the bodice front and back pieces. Press the seam allowances toward the back and serge.
6. Sew the shoulder seams of the facings and front bands. Press the seam allowances open. Serge the outer edge. Pin the center front facings to the garment, right sides together, and sew the center front edges and back neckline. Clip the curves and trim the corners. Turn the facings to the wrong side, shape, and press. Slipstitch the facings to the garment at the shoulder seams. Overlap the right front over the left front, matching the center front line, and baste together along the lower edge. Sew a gathering stitch along the lower edge of the front and gather the fullness.
7. Place the bodice and shorts wrong sides together. Sew 0.7 cm from the edge. Turn the pieces wrong side out, press, and sew again 1.3 cm from the first seam to create a clean enclosed seam. Press the seam allowances toward the shorts. Topstitch the seam allowances onto the shorts. Carefully make an opening for the elastic, finish the opening by hand, thread the elastic through, and sew the opening closed by hand.
8. Press the hem allowance up 1 cm, then fold it up another 1 cm and topstitch.
9. Make buttonholes on the right front and sew the buttons onto the left front.

Congratulations – your jumpsuit are finished! :)



Model 2318

pattern from pppp.dk