

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2334 Slide-on dress with tie belt

Recommendations on fabric:  
natural/mixed fabric suitable for dresses.  
Thin denim.  
You will also need: fusible interfacing; 3 hidden buttons

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

### Main fabric:

1. Back yoke - cut 1
2. Back - cut 2
3. Side - cut 2
4. Front — cut 2
5. Collar – cut 2
6. Center front facing- cut 2
7. Back neck facing – cut 1
8. Belt - cut 2



Fusible interfacing:

1. Collar – cut 1
2. Center front facing- cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Fold belt in half lengthwise right sides together and sew along longer and one shorter side. Turn belt right side out, straighten and press. Topstitch belt around all edges at 0.1 cm from edge.
3. Sew center back seam, press towards left and serge. Sew yoke to back, press towards top and serge. Sew side backs to center back, inserting one of the belts into the left seam, press towards center and serge.
4. Sew front darts on front, press bulk towards top. Sew side fronts to front, press towards center and serge.
5. Sew shoulder seams, press seams towards back and serge.
6. Pin upper collar to lower collar right sides together and sew collar end and collar fall. Seam Allowances trim away corners clip into seam allowance near notch, turn the collar right side out, straighten and press.
7. Pin button stand (center front facing) to front right sides together and sew buttonstand and lapel up to notch, inserting the second part of the belt into the right front edge. Clip into seam allowance near the notch, turn pieces right side out, straighten, press.
8. Sew shoulder seams of center front facings and of back facing, press seam apart. Serge outer edges.
9. Sew lower collar into self-neckline, and upper collar into neckline facings, press seam apart, baste together. Slip stitch seam edges of center front facings (button stands) to shoulder seams on garment.
10. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto edge of armhole from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along seam. Press seam.

11. Serge lower edge of dress, press onto wrong side and topstitch.

12. Make buttonholes on the left edge, sew on hidden buttons.

Congratulations, your dress is ready! :)