

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2339 T-shirt dress with gathers

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 1.5 cm.

Main fabric:

1. Back yoke – cut 1 on fold
2. Back – cut 1 on fold
3. Front yoke – cut 2
4. Front – cut 1 on fold
5. Cuff – cut 2
6. Front neck facing – cut 1
7. Back neck facing – cut 1

Fusible interfacing:

1. Front neck facing – cut 1
2. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew a gathering stitch along the upper edge of the back between the markings and gather the fullness. Sew the yoke to the back. Press the seam allowances upward and serge.
3. Sew the center seam of the front yoke. Press the seam allowances open and serge.
4. Sew a gathering stitch along the upper edge of the front between the markings and gather the fullness. Sew the front yoke to the front. Press the seam allowances upward and serge.
5. Sew the side and shoulder seams. Press the seam allowances toward the back and serge.
6. Sew the shoulder seams of the front and back neckline facings. Press the seam allowances open and serge the outer edge. Pin the facings to the garment, right sides together, and sew the front and back neckline. Clip the curves, turn the facings to the wrong side, shape, and press. Slipstitch the facings to the garment at the shoulder seams.
7. Sew the cuffs into rings, right sides together. Press the seam allowances open. Fold each cuff in half lengthwise, right side out, and press. Sew the outer edge of the cuff to the sleeve. Fold the seam allowance of the inner cuff edge under and stitch in the ditch along the seam joining the outer cuff. Turn the cuff to the right side.
8. Serge the garment hem, press it to the wrong side, and topstitch.

Congratulations – your dress are finished! :)