

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2386 Jacket with decorative peplum and belt

Recommendations on fabric: thin soft natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 5 buttons.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve - 3 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Placket – cut 2
5. Peplum – cut 1
6. Back neck facing – cut 1
7. Front neck facing – cut 2
8. Belt – cut 2

Lining:

1. Back – cut 1 on fold

2. Front – cut 2
3. Sleeve – cut 2
4. Lining of hidden button panel – cut 2

Fusible interfacing:

1. Placket – cut 2
2. Back neck facing – cut 1
3. Front neck facing – cut 2
4. Lining of hidden button panel – cut 1

Attention! Cut Back and Front from lining using the corresponding pieces for main fabric except for the width of back neckline facing and front neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on front, press bulk towards top.
3. Sew right side seam, press seam apart.
4. Serge lower edge of peplum, press onto wrong side and topstitch. Serge the upper edge of peplum, press onto wrong side along the marked line and topstitch with gathering stitch, gather fullness. Pin peplum onto right Front and Back of jacket and topstitch.
5. Fold belts in half lengthwise right sides together and sew the longer side and the shorter side. Turn belt right side out, straighten, press.
6. Sew left side seam, inserting the left side of belt, and shoulder seams, press seam apart.
7. Sew sleeve seam, press seam apart. Sew sleeves into armholes matching notches, press seam.
8. Sew the shoulder edges of back neckline facing and front neckline facing and press apart. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, press seam apart. Sew facing to lining, press seam allowances towards placket.
9. Pin lining to Front right sides together and sew the neckline. Clip into curves, turn garment right side out, straighten seams, press. Sew lining to lower edge of garment and lower edge of sleeve. Baste together main fabric and lining along center front edge.

Congratulations, your jacket is ready! :)