

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2400 Jacket with Peplum and Zip Closure

Recommendations on fabric: thin natural/mixed suiting fabrics.

You will also need: fusible interfacing; separating zipper.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3 cm.

### Main fabric:

1. Upper back – cut 2
2. Lower back – cut 1 on fold
3. Lower front – cut 2
4. Upper front – cut 2
5. Center front facing – cut 2
6. Back neck facing – cut 1
7. Upper sleeve – cut 2



## 8. Lower sleeve – cut 2

### Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1

### INSTRUCTIONS:

1. Apply fusible interfacing to the corresponding pieces, as well as to the hem allowances of the garment and sleeves.
2. Sew the shoulder and waist darts on the upper back pieces. Press the dart excess toward the center. Sew the center back seam, press the seam allowances toward the left, and serge. Sew the upper back to the lower back. Press the seam allowances upward and serge.
3. Sew the darts on the front pieces. Trim the dart excess to 1 cm, press it toward the center, and serge. Form and baste the pleats on the lower front pieces. Sew the upper front pieces to the lower front pieces. Press the seam allowances upward and serge.
4. Sew the shoulder and side seams. Press the seam allowances toward the back and serge.
5. Sew the side seams of the back neckline facing and front facings. Press the seam allowances open and serge the outer edge. Pin the front facings and neckline facing to the garment, right sides together. Insert the zipper between the layers and sew the center front edges, neckline, and lower corners. Trim the corners and clip the curves. Turn the facings to the wrong side, shape the edges, and press.
6. Sew the elbow seam and front sleeve seam. Serge and press the seam allowances. Set the sleeves into the armholes, matching the notches. Serge and press.
7. Serge the garment hem and sleeve hems. Press them to the wrong side and topstitch.

Congratulations – your jacket are finished! :)