

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2419 Short Jacket with Notched Collar

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads.



CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2.5 cm. Seam allowance for hem of sleeve – 2.5 cm.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Lower collar – cut 1
6. Upper collar – cut 1
7. Center front facing – cut 2

8. Back neck facing – cut 1
9. Sleeve – cut 2

Attention: lining for front and back is cut using the pattern blocks for main fabric except for the width of the center front facing and back neckline facing.

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Sleeve – cut 2

Fusible interfacing:

1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply a strip of interfacing 1 cm wide along the lapel fold line on the fronts.
2. Sew the center back seam and press it open. Sew the side backs to the center back. Press seams toward the center.
3. Sew the side fronts to the center fronts. Press seams toward the center.
4. Sew the shoulder and side seams. Press seams open.
5. Pin the upper collar to the lower collar and sew corners and collar fall. Start and stop stitching exactly at the marked line of the seam between the collar and garment. Trim corners, clip into seam allowances near the notch, turn the collar right side out, straighten, and press.
6. Sew and press open the shoulder seams of the back neckline facing and buttonstands.
7. Place the center front facing onto the front, right sides together. Pin and sew along the center front edge, stitching upwards to the notch marking the end of the collar seam.

8. Sew the lower collar into the neckline of the jacket. Sew the upper collar into the neckline of the back facing and center front facing. Press the seam allowances of the collar seam open and slipstitch them together close to the seam.
9. Sew the sleeve seams and press them toward the back. Sew the sleeves into the armholes, matching notches and easing along the upper side of the sleeve cap. Sew in shoulder pads.
10. Press the hems of the sleeves and jacket to the wrong side.
11. Sew the lining seams, leaving an opening in the left sleeve. Sew the lining to the buttonstands and facing. Sew the lining to the hem of the jacket and sleeve hems.
12. Turn the jacket right side out through the opening. Sew the opening closed.

Congratulations – your jacket are finished! :)