

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2448 Wrap Blouse with Peplum

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing, 3 buttons.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: seam allowance for hem of garment and hem of sleeve – 1.5 cm, other seams – 1 cm.

### Main fabric:

1. Upper back – cut 2
2. Back belt – cut 2
3. Lower back – cut 1
4. Upper front – cut 2
5. Front belt – cut 4
6. Lower front – cut 2
7. Sleeve – cut 2

Fusible interfacing:

1. Front belt – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew the darts on the upper back pieces and press the dart excess toward the center. Sew the center back seam of the upper back pieces, press the seam allowances toward the left, and serge.
3. Sew a gathering stitch along the lower edge of the upper front and gather the fullness evenly.
4. Sew the shoulder and side seams of the upper part of the garment. Press the seam allowances toward the back and serge.
5. Cut (or use a ready-made) bias tape 4 cm wide and long enough to match the back neckline and front neckline plus 4 cm. Fold the bias tape in half lengthwise, right side out, and press. Pin the bias tape to the neckline from the right side, leaving the ends free, and sew. Fold the bias tape to the wrong side, clip into the seam allowances where necessary, and topstitch along the seam from the right side. Press.
6. Sew the back belt to the front belt and press the seam allowances open. Sew the side seams of the lower part of the garment. Press the seam allowances toward the back and serge.
7. Serge the slanted edges of the lower front pieces, press them to the wrong side, and topstitch. Pin the belt pieces together, right sides together, inserting the lower part of the garment between them, and sew. At the same time, sew the center front edge of the belt. Start and stop stitching exactly at the marked seam line along the upper edge.
8. Sew the outer belt to the outer side of the garment. Press the seam allowances toward the belt. Fold the seam allowance of the inner belt edge under, press, and stitch in the ditch from the right side.
9. Sew the sleeve seam. Press the seam allowances toward the back and serge. Sew a gathering stitch along the sleeve cap and gather the fullness evenly. Set the sleeves into the armholes, matching the notches and distributing the ease. Serge and press.
10. Serge the garment hem and sleeve hems. Press them to the wrong side and topstitch.
11. Make a button loop on the right front and sew a button onto the left front. Make an inner buttonhole on the left front and sew on a hidden button. Sew a decorative button onto the right front.

Congratulations – your blouse are finished! :)