

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2466 Jumper Dress with Open Shoulders

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; lining; dress zipper.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: Seam allowance for hem of garment – 3 cm. Seam allowance along the vent edge – 6 cm. Other seams – 1 cm.

Main fabric:

1. Upper center back – cut 4
2. Lower center back – cut 2
3. Side back – cut 2
4. Side front – cut 2
5. Upper center front – cut 2
6. Lower center front – cut 1

Lining:

1. Upper side back – cut 2
2. Upper side front – cut 2

Fusible interfacing:

1. Upper center back – cut 2
2. Upper center front – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
 2. Sew the upper center back to the lower center back. Press the seam allowances upward and serge. Sew the upper center front to the lower center front. Press the seam allowances upward and serge.
 3. Sew the shoulder seams of the center fronts and center backs. Press the seam allowances open. Sew the shoulder seams of the inner center fronts and inner center backs. Press the seam allowances open. Serge the lower edges.
 4. Pin the inner and outer center front and center back pieces together, right sides facing, and sew the neckline. Clip into the curves, turn right side out, and press.
 5. Sew the side seams of the garment. Press the seam allowances toward the back and serge.
 6. Sew the side seams of the lining. Press the seam allowances toward the back and serge the lower edge. Pin the lining to the garment, right sides together, and sew the armhole edges. Turn right side out, shape, and press. Baste the lining to the garment along the princess seam edges and treat them as one layer in the following steps.
 7. Sew the princess seams on the front and back (sew the side backs to the center backs and the side fronts to the center fronts), inserting the side pieces between the outer center pieces and the inner center pieces. Press the seam allowances toward the center and serge.
 8. Trim 5 cm from the vertical edge of the vent on the left back piece. Apply fusible interfacing to the vent area on the back pieces from the wrong side. Mark the center back seam line (vent fold line) on the right side. Press the left vent extension along the fold line. On the right side, press only the vent seam allowance (6 cm) to the wrong side. Align the back pieces and baste them together along the upper edge of the vent. Serge the center back edges separately, including the vent seam allowances. Sew the center back seam from the zipper marking to the vent corner. Clip into the seam allowance at the vent corner on the right side. Press the center back seam open, press the vent seam allowances, and secure them with machine stitching. Insert the zipper.
 9. Press the hem allowance of the garment to the wrong side and topstitch or hand-finish the hem as desired.
- Congratulations – your dress are finished! :)