

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2499 Coat with three buttons

Recommendations on fabric: natural/mixed fabrics suitable for coats.

You will also need: fusible interfacing, lining, 3 big buttons, hidden button, shoulder pads, sleeve heads.



### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of coat and hem of sleeve 3 cm.

### Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Back neck facing – cut 1
8. Center front facing – cut 2

Lining:

1. Center back – cut 2
2. Center front – cut 2
3. Side back – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Attention: lining is cut using pattern blocks for self-fabric except for the area of center front facing and back neckline facing.

Fusible interfacing:

1. Center front – cut 2
2. Back neck facing – cut 1
3. Center front facing – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back. Press bulk towards center. Sew side backs to center back. Press seam apart. Sew center back seam. Press seam apart.
3. Sew dart on center front. Slash dart in half lengthwise and press apart. Sew side fronts to front. Seam Allowances press apart.
4. Sew side seams of coat and press apart. Clip into seam allowance in the corner near shoulder seam. Sew collar seam. Press seam apart. Sew shoulder seams, sewing collar into the neckline at the same time.
5. Sew the elbow seam of the sleeve and press it apart. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches. Sew shoulder pads, sew sleeve heads.
6. Sew seams on lining and sew in sleeves, leaving an opening for turning in front right sleeve seam. Sew shoulder seams of button stands and facings, clipping into seam allowances near corners. Sew collar seam on center front facings. Press seam apart. Sew collar into neckline. Press seam apart. Sew lining to button stands and facing.
7. Place center front facing onto front right sides together, pin together and sew along center front edge and along the hem. Sew lining to hem of sleeve. Turn coat right side out through the opening. Slip stitch seam allowances along the seams of inner and outer collars together. Sew the opening in sleeve closed. Sew a decorative stitch along center

front edge and collar at 0.5 cm from the edge.

8. Make buttonholes on right front. Sew on buttons on the left front. Make the inner buttonhole. Sew on inner button.

Congratulations, your coat is ready! :)