

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2507 Jacket without closure

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing, lining, fusible interfacing, shoulder pads.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3 cm.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Placket - cut 2
6. Collar – cut 1
7. Back neck facing – cut 1
8. Center front facing – cut 2

Lining:

1. Back – cut 2

2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2

Fusible interfacing:

1. Placket – cut 2
2. Collar – cut 1
3. Center front facing – cut 2
4. Back neck facing – cut 1

Lining is cut using pattern blocks for front and back for the main fabric except for the width of center front facing and facing

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back Press bulk towards center. Sew center back seam, press seam apart.
3. Sew shoulder and side seams. Press seam apart.
4. Fold placket in half lengthwise right sides together and sew lower and upper corners. Trim seam allowances, turn right side out and press. Fold collar in half lengthwise right sides together and sew corners. Trim seam allowances, turn right side out and press.
5. Sew placket to center front edge of the jacket. Sew collar into neckline of jacket. Press towards the main piece.
6. Sew sleeve seam, press towards back part. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew on shoulder pads. Sew shoulder seams facings and center front facings. Press seam apart. Sew center front facings and facing to the collar and to the placket. Clip seam allowances, and press.
7. Hem of sleeve and of jacket press onto wrong side.
8. Sew seams on lining, leaving an opening in left sleeve. Sew lining to center front edges and to neckline. Sew lining to center front edges, to facing, to hem of jacket and to sleeves.
9. Turn jacket right side out through the opening. Sew the opening closed.

Congratulations, your jacket is ready! :)