

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2521 Reversible Hooded Jacket

Recommendations on fabric: natural/mixed fabrics suitable for jackets in 2 similar or contrasting colors.

You will also need: lining; separating zipper; decorative cord; 2 zippers; 2 cord stops, 2 grommets.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance along the upper edge of the patch pocket – 2 cm.

Main fabric 1:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Hood – cut 2

Main fabric 2:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Hood – cut 2

5. Patch pocket – cut 2

Lining:

1. Large pocket bag – cut 2
2. Small pocket bag – cut 2
3. Casing for drawstring – cut 1

INSTRUCTIONS:

Main Fabric 2

1. Fold the upper seam allowance of the patch pocket to the wrong side twice by 1 cm and topstitch. Fold the seam allowances of the lower and center edges to the wrong side and press. Pin the pocket to the front according to the markings and topstitch along the side and lower edges.
2. Sew the shoulder seams and press the seam allowances open. Set the sleeves into the armholes and press the seams. Sew the side seams and sleeve seams. Press the seam allowances toward the back. Sew the hood into the neckline and press the seam allowances open.

Main Fabric 1

1. Mark the pocket position with parallel lines. Cut the slit for the pocket opening and clip diagonally 1–1.5 cm from each end of the marked slit. Turn the seam allowances to the wrong side through the opening and straighten the edges. Pin the zipper underneath the opening so that the zipper teeth are visible and sew it in place. Sew one side of the pocket lining to the wrong side of the zipper tape. Sew the edges of the pocket lining together.
 2. Sew the shoulder seams and press the seam allowances open. Set the sleeves into the armholes and press the seams. Sew the side seams and sleeve seams, leaving an opening in the left sleeve seam for turning. Press the seam allowances toward the back. Sew the hood into the neckline and press the seam allowances open.
 3. Install the eyelets on the front. Pin the casing to the front and back from the wrong side and sew along the marked lines.
 4. Pin the two jacket layers together, right sides facing. Insert the separating zipper and sew the center front edges. Sew the hood edge, lower edge of the jacket, and lower sleeve edges. Turn the jacket right side out through the opening. Press the seams and sew the opening closed. Thread the decorative cord through the casing and attach the cord locks and cord ends.
 5. Sew a securing topstitch 1.5–2 cm from the edge around the hood, along the zipper, and around the sleeve hems.
- Congratulations – your jacket are finished! :)