

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2531 Loose jacket with patch pockets

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing, 1 button.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve – 3 cm.

### Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Cuff – cut 2
5. Back neck facing – cut 1
6. Center front facing – cut 2
7. Collar - cut 1
8. Pocket – cut 2



Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Cuff - cut 2
4. Collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the upper seam allowance of pocket.
2. Serge upper seam allowance of pocket. Fold the seam allowance onto wrong side and topstitch. Center and lower press onto wrong side and topstitch onto front according to markings. Baste the pocket to the main piece along the side seam.
3. Sew shoulder seams. Serge seams and press towards back.
4. Sew in sleeves. Press the seam allowances towards the main piece. Sew side seams and sleeve seams. Press seams towards back. Sew cuff into a ring, press seam apart. Pin the right side of cuff to the wrong side of sleeve and sew. Fold the cuff upwards, onto right side. Fold seam allowances onto wrong side and topstitch onto sleeve.
5. Sew corners of collar. Trim seam allowances, turn right side out and press. Sew collar into neckline.
6. Sew shoulder seams of buttonstands and facings. Press seam apart. Serge outer edge. Pin center front facing and facing onto garment and sew center front edge and neckline. Clip seam allowances, straighten seams and press. Slip stitch facing to shoulder seams.
7. Place center front facing onto front right sides together and sew along the center front edge, inserting zipper, sewing the collar at the same time.
8. Seam allowance for hem serge, press onto wrong side and finish with hidden stitches.
9. Make a buttonhole and sew on button.

Congratulations, your jacket is ready! :)