

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2582 Sleeveless Blouse with Peplum Flounce

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance along hem of garment – 2 cm.

Main fabric:

1. Upper back – cut 1 on fold
2. Back inset – cut 1
3. Lower back – cut 1 on fold
4. Lower front left – cut 1
5. Lower front right – cut 1
6. Front inset left – cut 1
7. Front inset right – cut 1
8. Upper front left – cut 1
9. Upper front right – cut 1
10. Back neck facing – cut 1

11. Front neck facing – cut 2

Fusible interfacing:

1. Back neck facing – cut 1
2. Front neck facing – cut 2

INSTRUCTIONS:

Apply fusible interfacing.

1. Sew the darts on the upper back and press the dart excess toward the center. Sew the back inset to the upper back. Press the seam allowances toward the inset and serge.
2. Sew a gathering stitch along the upper edge of the lower back and gather the fullness. Sew the lower back to the back inset. Press the seam allowances upward and serge.
3. Sew the darts on the left upper front and right upper front. Press the dart excess toward the center of each piece. Sew the front insets to the upper fronts. Press the seam allowances toward the insets and serge.
4. Sew gathering stitches along the upper edges of the left and right lower front pieces and gather the fullness. Sew the lower front pieces to the front insets. Press the seam allowances upward and serge.
5. Serge the outer and lower edges of the front neckline facings. Pin the neckline facings to the left and right front pieces and sew the neckline. Turn the facings to the wrong side, shape, and press.
6. Sew the left front to the right front. Press the seam allowances and serge. Form a pleat on the right front, matching the center lines. Sew a decorative securing stitch along the width of the pleat.
7. Serge the outer edge of the back neckline facing. Pin the neckline facing to the back and sew the neckline exactly to the marked shoulder seam line. Clip the seam allowances, turn the facing to the wrong side, and press.
8. Sew the shoulder seams, placing the front between the back and the facing. Press the seam allowances toward the back and serge.
9. Cut or use ready-made bias tape 4 cm wide and long enough to match the armhole length plus 4 cm. Fold the bias tape in half lengthwise, right side out, and press. Pin the bias tape to the armhole edge from the right side and sew. Fold the bias tape to the wrong side and topstitch along the seam from the right side. Press.
10. Serge the left side edges separately. Sew the left side seam from the armhole to the first marking and from the second marking to the hem. Press the seam allowances open. Insert the zipper. Sew the right side seam, press the seam allowances toward the back, and serge.
11. Serge the lower edge of the garment, press it to the wrong side, and topstitch.
Congratulations – your blouse are finished! :)