

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2615 Short Coat with Stand Collar and Pockets

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining, fusible interfacing; 8 sew-on push buttons; shoulder pads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of coat and hem of sleeve - 3.0 cm.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Front side – cut 2
4. Sleeve – cut 2
5. Collar – cut 2
6. Center front facing – cut 2
7. Back neck facing – cut 1

8. Pocket – cut 2

Lining:

1. Back – cut 2
2. Front lining – cut 2
3. Sleeve – cut 2
4. Pocket lining – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Collar – cut 1

The lining for back and for front is cut using the pattern pieces for the main fabric except for the width of the back neckline facing and of the center front facing.

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the one-piece pocket facing. Apply fusible interfacing to the sleeve hem allowance.
2. Sew the center back seam and press the seam allowances open.
3. Sew the darts on the front. Trim the dart excess to 1 cm. Clip the seam allowance at the dart point, gradually reducing the remaining seam allowance. Press the seam allowances open.
4. Sew the pocket lining to the one-piece pocket facing and press the seam allowance toward the lining. Fold the pocket along the marked line and press. Pin the pocket to the front side piece and baste along the princess seam edge, lower edge, and side edge.
5. Sew the side front piece to the front, clipping into the seam allowance at the front corner. Press the seam allowances open.
6. Sew the shoulder and side seams and press the seam allowances open. Sew the outer collar into the front and back neckline. Press the seam allowances open.
7. Sew the sleeve seams and press the seam allowances open. Press the sleeve hem allowance to the wrong side. Set the sleeves into the armholes and press the seams. Sew in the shoulder pads.
8. Sew the shoulder seams of the back neckline facing and center front facings. Press the seam allowances open. Sew the inner collar into the neckline of the center front facings and back neckline facing. Press the seam allowances open.
9. Turn the lower edge of the coat to the wrong side and press. Place the center front facings onto the front pieces, right sides together, and sew the center front edges and collar. Clip into the seam allowances at the corners. Turn the center front facings

- right side out, shape the seams, and press. Sew the collar seam allowances together.
10. Assemble the lining, leaving an opening in the left sleeve seam for turning. Sew the lining to the center front facings, back neckline facing, garment hem, and sleeve hems. Turn the coat right side out through the opening and sew the opening closed.
 11. Sew on the snap buttons according to the markings.

Congratulations – your coat are finished! :)