

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2643 Jacket with Asymmetrical Lapel

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; shoulder pads; 1 button.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams – 1 cm. Seam allowance for hem of garment and hem of sleeve – 3 cm.

Main fabric:

1. Right center back – cut 1
2. Left center back – cut 1
3. Side back – cut 2
4. Side front – cut 2
5. Left center front – cut 1
6. Right center front – cut 1
7. Sleeve – cut 2
8. Center front facing left – cut 1
9. Center front facing right – cut 1



10. Collar – cut 1
11. Facing of left front – cut 1

Fusible interfacing:

1. Back neck facing – cut 1
2. Collar – cut 1
3. Center front facing – cut 1
4. Facing of left front – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
 2. Sew the side back pieces to the center back. Serge the seam allowances and press them toward the side pieces.
 3. Sew the side front pieces to the front. Serge the seam allowances and press them toward the side pieces.
 4. Sew the shoulder seams. Serge the seam allowances and press them toward the back.
 5. Cut or use ready-made bias tape 2.5 cm wide and 40 cm long. Fold the tape in half lengthwise, wrong sides together, and stitch 0.5 cm from the fold. Turn the tape right side out and shape the tie. Cut it into two equal parts.
 6. Sew the side seams, inserting one tie into the left side seam. Serge the seam allowances and press them toward the back.
 7. Sew the shoulder seams of the back neckline facing and center front facings. Press the seam allowances open and serge the outer edge.
 8. Form the pleats on the collar, directing the pleat excess downward. Pin the collar to the right center front, right sides together, and sew the lapel. Stop stitching exactly at the center front facing seam line. Clip into the seam allowance at the shoulder edge and sew the collar into the back neckline. Sew the center back seam, inserting the center edge of the collar. Serge the seam allowances and press them toward the left.
 9. Sew the center front facings and back neckline facing to the garment, inserting the right tie. Clip into the seam allowances along the center front edge. Turn the facings to the wrong side and press. Slipstitch the facing to the garment along the shoulder seam.
 10. Sew the sleeve seams. Serge the seam allowances and press them toward the back.
 11. Set the sleeves into the armholes, matching the notches and easing the fullness along the upper sleeve cap. Serge the seam allowances and press. Sew in the shoulder pads.
 12. Serge the garment hem and sleeve hems. Fold the seam allowances to the wrong side and topstitch.
 13. Make a buttonhole and sew on the inner button.
- Congratulations – your jacket are finished! :)