

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2650 Dress with Sleeve Flounces

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams – 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm.

Main fabric:

1. Back yoke – cut 2
2. Center back – cut 2
3. Side back – cut 2
4. Front yoke – cut 1
5. Center front – cut 1 on fold
6. Side front – cut 2
7. Upper sleeve – cut 2
8. Lower sleeve – cut 2



9. Back neck facing – cut 2
10. Front neck facing – cut 1

Fusible interfacing:

1. Back neck facing – cut 2
2. Front neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew the side back pieces to the center back. Press the seam allowances toward the center and serge. Sew the yoke to the back. Press the seam allowances upward and serge.
3. Serge the center back edges separately. Sew the center back seam from the zipper marking to the lower edge. Press the seam allowances open and insert the zipper.
4. Sew the side front pieces to the front. Press the seam allowances toward the center and serge. Sew the yoke to the front. Press the seam allowances upward and serge.
5. Sew the side and shoulder seams. Press the seam allowances toward the back and serge.
6. Sew the shoulder seams of the neckline facings and press the seam allowances open. Serge the outer edge. Pin the facing to the garment, right sides together, and sew the neckline. Clip into the curves, turn the facing to the wrong side, and press. Slipstitch it to the shoulder seams.
7. Form and baste the box pleats on the lower sleeve. Sew the upper sleeve to the lower sleeve. Press the seam allowances upward and serge.
8. Sew the sleeve seams. Press the seam allowances toward the back and serge. Set the sleeves into the armholes, serge the seam allowances, and press.
9. Serge the hem allowance of the dress and sleeve hems. Press them to the wrong side and topstitch.

Congratulations – your dress are finished! :)