

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2667 Double-Breasted Coat with Shawl Collar

Recommendations on fabric: thin natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 2 buttons; shoulder pads.

### CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams – 1 cm. Seam allowance for hem of garment and hem of sleeve – 3 cm.

### Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Lower back – cut 2
4. Center front – cut 2
5. Side front – cut 2
6. Lower front – cut 2
7. Upper sleeve – cut 2



8. Lower sleeve – cut 2
9. Center front facing – cut 2
10. Back neck facing – cut 1

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Lower back – cut 2
4. Center front – cut 2
5. Side front – cut 2
6. Lower front – cut 2
7. Upper sleeve – cut 2
8. Lower sleeve – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Upper front – cut 2

**Attention!** Lining is cut using the pattern pieces for main fabric, except for the width of the center front facing and the back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew the center back seams of the upper and lower back pieces and press the seam allowances open. Sew the side back pieces to the center back and press the seam allowances open. Sew the upper back to the lower back and press the seam allowances open.
3. Sew the side front pieces to the front and press the seam allowances open. Sew the upper front to the lower front and press the seam allowances open.
4. Sew the shoulder and side seams. Press the seam allowances open.
5. Sew the center seam of the one-piece collar. Sew the one-piece collar into the neckline, clipping into the seam allowance near the corner.
6. Sew the shoulder seams of the center front facings and back neckline facing. Press the seam allowances open. Sew the center collar seam. Sew the collar into the neckline of the facings, clipping into the seam allowance near the corner. Pin the center front facings to the garment, right sides together, and sew the center front edges, lapels, collar, and lower edges. When stitching, keep the front piece on top. Understitch the center front seam allowances to the facings 0.2 cm from the seam. Turn the facings to the wrong side, shape, and press.

7. Sew in the shoulder pads.
8. Sew the elbow seams of the sleeves and press the seam allowances open. Press the sleeve hem allowances to the wrong side. Sew the front sleeve seams and press the seam allowances toward the lower sleeve pieces. Set the sleeves into the armholes, matching the notches, and press the seams.
9. Fold the garment hem allowance to the wrong side and press.
10. Assemble the lining, leaving an opening in the left sleeve elbow seam. Sew the lining to the back neckline facing and center front facings. Sew the lining to the garment hem and sleeve hems. Turn the garment right side out through the opening and sew the opening closed.
11. Make buttonholes on the right front and sew the buttons onto the left front.

Congratulations – your coat are finished! :)