

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2671 Jacket with Gathered Peplum

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: lining; fusible interfacing; shoulder pads; 6 buttons; decorative tape (approximate length is given on the front pattern piece).



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams – 1 cm. Seam allowance along hem of jacket and hem of sleeve – 3 cm.

Main fabric:

1. Upper back – cut 2
2. Lower back – cut 1 on fold
3. Upper front – cut 2
4. Lower front – cut 2
5. Sleeve – cut 2
6. Stand collar – cut 2

7. Back neck facing – cut 1
8. Center front facing – cut 2

Lining:

1. Upper back – cut 2
2. Lower back – cut 1 on fold
3. Upper front – cut 2
4. Lower front – cut 2
5. Sleeve – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Stand collar – cut 1

Attention! Cut Back and Front from lining using the corresponding pieces for main fabric except for the width of back neckline facing and front neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew the darts on the back. Trim the dart excess and press it toward the center. Sew the center back seam and press the seam allowances open.
3. Sew a gathering stitch along the upper edge of the lower back and gather the fullness. Sew the upper back to the lower back. Press the seam allowances upward.
4. Sew the darts on the front. Trim the dart excess and press it toward the center. Mark the button positions on the left front. Topstitch the decorative band along the center line.
5. Sew a gathering stitch along the upper edge of the lower front and gather the fullness. Sew the upper front to the lower front. Press the seam allowances upward.
6. Sew the shoulder and side seams. Press the seam allowances open.
7. Pin the stand collar pieces together, right sides facing, and sew along the upper edge. Clip into the seam allowances along the curves, turn the stand collar right side out, shape, and press. Sew the stand collar into the neckline.
8. Sew the shoulder seams of the back neckline facing and center front facings. Press the seam allowances open. Pin the center front facings and back neckline facing to the garment, right sides together, and sew the center front edges, neckline, and lower center front corners. Trim the corners. Understitch the center front seam allowances to the facings 0.2 cm from the seam. Turn the facings to the wrong side, shape the seams, and press. Press the lower edge of the garment.
9. Sew the sleeve seams and press the seam allowances open. Set the sleeves into the

armholes, matching the notches, and press the seams. Sew in the shoulder pads.

10. Assemble the lining in the same way as the main fabric, leaving an opening in the left sleeve seam. Sew the lining to the center front facings and back neckline facing. Press the seam allowances toward the facings. Sew the lining to the garment hem and sleeve hems. Turn the jacket right side out through the opening and sew the opening closed.
11. Make buttonholes on the right front and sew the buttons onto the left front.

Congratulations – your jacket are finished! :)