

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2684 A-Line Coat with Lapels and Belt

Recommendations on fabric: natural/mixed fabrics suitable for raincoats.

You will also need: fusible interfacing; 5 buttons; lining; shoulder pads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams – 1 cm. Seam allowance for hem of garment and hem of sleeve – 2 cm, along the edges of pocket bags and pocket welts – 2 cm.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Yoke – cut 1
4. Facing yokes – cut 1
5. Center front – cut 2
6. Side front – cut 2
7. Center front facing – cut 2



8. Upper sleeve – cut 2
9. Lower sleeve – cut 2
10. Back neck facing – cut 1
11. Upper collar – cut 1
12. Lower collar – cut 1
13. Pocket welt – cut 2
14. Sleeve decorative tab – cut 2
15. Belt – cut 1
16. Belt Loop – cut 1

Lining:

1. Side back – cut 2
2. Side front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Back lining – cut 2
6. Center front – cut 2
7. Large pocket bag – cut 2
8. Small pocket bag – cut 2

Attention: The front pieces from lining are cut using the pattern pieces for the main fabric except for the width of the center front facings.

Fusible interfacing: center front facing, back neck facing, upper collar.

INSTRUCTIONS:

Attention: Serge the princess seam allowances and side seam allowances from the waistline to the hem.

1. Apply fusible interfacing to the center front facings, back neckline facing, upper collar, front armhole edges, and back armhole edges. Apply fusible interfacing to the pocket area on the side front pieces. Apply a 1 cm wide strip of fusible interfacing along the lapel fold lines on the front pieces.
2. Mark the pocket positions. Fold each welt in half lengthwise, wrong sides together, and press. Topstitch the small pocket bag to the inner side of the welt. Sew the welt to the front along the lower pocket marking line. Sew the large pocket bag to the front along the upper pocket marking line. Stop stitching at the short pocket marking lines. Cut the pocket opening and clip diagonally toward the ends of the stitching, stopping 1–1.5 cm from each end. Turn the welt and large pocket bag to the wrong side through the opening. Secure the pocket ends with double

- backstitching near the corners. Sew the pocket bag edges together.
3. Sew the side front pieces to the front. Press the seam allowances toward the center.
4. Sew the center back seam and press the seam allowances open.
5. Sew the facing to the lower edge of the yoke and clip into the seam allowances. Turn the facing to the wrong side, press, and sew a decorative topstitch 0.5 cm from the edge. Pin the yoke to the back and topstitch along the yoke edge.
6. Sew the side back pieces to the center back. Press the seam allowances toward the center.
7. Sew the shoulder and side seams. Press the seam allowances open.
8. Sew the back neckline facing to the center front facings. Press the seam allowances open.
9. Pin the collar pieces together, right sides facing, and sew the collar ends and outer edge. Clip into the seam allowances near the notches. Turn the collar right side out and press.
10. Serge the lower edge of the garment and press the hem allowance to the wrong side. Place the center front facings onto the front pieces, right sides together, and sew along the center front edges and lower edges exactly along the marked lines. Sew upward to the notches marking the ends of the collar seam. Clip into the seam allowances at the upper and lower corners of the center front facings. Understitch the center front seam allowances to the facings along the closure and to the front along the section that folds outward, placing the stitch line 0.2 cm from the seam. Turn the center front facings to the wrong side and shape the seams. Topstitch the lower edge of the garment.
11. Sew the lower collar into the garment neckline. Sew the upper collar into the neckline of the back neckline facing and center front facings. Press the seam allowances open. Sew the upper and lower collar seam allowances together by hand. Turn the garment right side out and press.
12. Serge one long edge of the belt loop strip. Fold the seam allowances toward the center, placing the serged edge on top, and press. Cut the strip into 10 equal belt loops.
13. Topstitch the belt loops onto the sleeve pieces. Sew the elbow seams and press the seam allowances open. Press the sleeve hem allowances to the wrong side. Sew the front sleeve seams and press the seam allowances open.
14. Set the sleeves into the armholes, matching the notches. Sew in the shoulder pads.
15. Assemble the lining and set in the sleeves. Fold the lower edge of the lining to the wrong side twice by 1 cm and topstitch.
16. Sew the lining to the inner edges of the center front facings and back neckline facing. Sew the lining to the sleeve hems.
17. Sew decorative topstitching along the center front edges and collar.
18. Fold each tab in half lengthwise, right sides together, and sew, leaving an opening for turning. Turn the tab right side out through the opening and sew the opening

closed. Sew decorative topstitching around all edges 0.5 cm from the edge.

19. Fold the belt in half lengthwise, right sides together, and sew, leaving an opening for turning. Turn the belt right side out through the opening and sew the opening closed. Sew decorative topstitching around all edges 0.5 cm from the edge.

20. Sew the belts in place at the level of the princess seams on the front and back.

21. Make buttonholes on the right front and tabs. Sew on the corresponding buttons.

Congratulations – your coat are finished! :)