

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2689 Sporty Style Jacket

Recommendations on fabric: soft suiting fabrics, natural/mixed corduroy fabrics.

You will also need: fusible interfacing; 9 buttons.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams – 1 cm.

Main fabric:

1. Center back – cut 1 on fold
2. Side back – cut 2
3. Back yoke – cut 1
4. Front yoke – cut 2
5. Center front – cut 2
6. Center 2 front – cut 2
7. Side front – cut 2
8. Front sleeve – cut 2
9. Back sleeve – cut 2

10. Collar – cut 2
11. Cuff – cut 2
12. Pocket welt – cut 2
13. Flap – cut 4
14. Placket – cut 1 on fold
15. Large pocket bag – cut 2
16. Small pocket bag – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Cuff – cut 2
3. Flap – cut 2
4. Pocket welt – cut 2
5. Placket – cut 1 on fold

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to the one-piece front placket.
2. Sew the side back pieces to the center back. Serge the seam allowances and press them toward the center. Sew a decorative topstitch 0.5 cm from the seam. Sew the back yoke to the back. Serge the seam allowances and press them upward.
3. Pin the pocket flap pieces together in pairs, right sides facing, and sew the side and lower edges. Trim the seam allowances, turn the flaps right side out, and press. Sew decorative topstitching along the side and lower edges.
4. Sew the side front pieces to the front. Serge the seam allowances and press them away from the center front piece. Sew decorative topstitching 0.5 cm from the seams. Sew decorative stitching to imitate a pocket. Sew the front yoke to the front, inserting the pocket flap. Serge the seam allowances and press them upward. Sew a decorative topstitch 0.5 cm from the seam.
5. Mark the pocket position. Fold the welt in half lengthwise, wrong sides together, and press. Topstitch the small pocket bag to the inner side of the welt. Sew the welt to the front along the lower pocket marking line. Sew the large pocket bag to the front along the upper pocket marking line. Stop stitching at the short pocket marking lines. Cut the pocket opening and clip diagonally toward the ends of the stitching, stopping 1–1.5 cm from each end. Turn the welt and large pocket bag to the wrong side through the opening. Secure the pocket ends with double backstitching near the corners. Sew the pocket bag edges together.
6. Sew the side and shoulder seams. Press the seam allowances toward the back and serge.
7. Fold the one-piece front placket to the wrong side. Sew the upper corner up to the

center line. Clip the seam allowance at the corner and near the center line. Turn the placket right side out and press the center front edge. Fold under the long seam allowance of the placket and topstitch.

8. Pin the upper collar to the lower collar, right sides together. Sew the collar ends and outer edge. Trim the seam allowances, turn the collar right side out, shape, and press. Sew decorative topstitching along the collar ends and outer edge.
9. Sew the upper collar into the garment neckline. Fold the seam allowance of the lower collar to the wrong side and stitch in the ditch along the upper collar seam.
10. Clip into the seam allowance near the marking on the front sleeve. Serge the slit seam allowance. Sew the front sleeve to the back sleeve from the upper edge to the slit marking. Serge the seam allowances and press them toward the back. Sew a decorative topstitch along the back sleeve 0.5 cm from the seam. Sew a securing stitch along the slit on the front sleeve.
11. Sew the sleeve seams. Press the seam allowances toward the back and serge.
12. Set the sleeves into the armholes, serge the seam allowances, and press. Sew a gathering stitch along the lower edge of each sleeve and gather the fullness at the back of the sleeve.
13. Fold the cuffs in half lengthwise, right sides together, and sew the side edges and corners. Start and stop stitching exactly at the marked cuff seam lines. Turn the cuffs right side out and press. Sew the outer cuff edge to the sleeve. Fold the inner cuff edge to the inside and stitch in the ditch along the outer cuff seam.
14. Fold the lower band in half lengthwise, right sides together, and sew the side edges. Start and stop stitching exactly at the marked seam lines. Turn the band right side out and press. Sew the outer edge of the band to the garment hem. Fold under the seam allowance of the inner edge and stitch in the ditch along the outer band seam. Sew decorative topstitching along all edges of the band.
15. Make buttonholes on the right front, cuffs, and pocket flaps. Sew the buttons onto the left front, pockets, and cuffs.

Congratulations – your jacket are finished! :)