

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2735 Vest with Shirt Collar.

Recommendations on fabric: natural/mixed suiting fabrics approx. 1.9 m (size 32-42), approx. 2.3 m (size 44-54) with a fabric width of 150 cm. You will also need: fusible interfacing, 13 push buttons.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams – 1 cm.

Main fabric:

1. Back – cut 1 on fold
2. Back yoke – cut 1
3. Front yoke – cut 2
4. Front – cut 2
5. Collar – cut 2
6. Stand collar – cut 2
7. Pocket – cut 2
8. Flap – cut 4
9. Lower placket – cut 1 on fold
10. Front placket – cut 2

11. Decorative Tab – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Stand collar – cut 1
3. Flap – cut 2
4. Front placket – cut 2
5. Lower placket – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on the back. Press the bulk towards the center.
3. Pin the pocket flaps together pairwise, right sides together, and sew the side and lower edges. Trim the seam allowances, turn right side out, and press. Sew a decorative stitch along the lower edge and the side edges.
4. Make and baste a box pleat on the pocket. Serge the upper edges of the pocket. Fold the upper seam allowances onto the wrong side, topstitch, and press. Serge the lower and side seam allowances of the pocket. Fold the lower and side seam allowances onto the wrong side, press, and pin the pocket onto the front according to the markings and sew. Sew the front yoke to the front, inserting the flap. Serge the seams and press towards the top. Sew a decorative stitch at 0.5 cm from the seam.
5. Sew the outer edge of the front placket to the front. Press the seam allowance at the placket. Fold the placket onto the wrong side, fold inside the open edge, and topstitch into the seam of the outer side.
6. Sew shoulder seams, press towards the back, and serge.
7. Pin the upper collar to the lower collar, right sides together. Sew the ends of the collar and the collar fall. Trim the seam allowances. Turn the collar right side out, straighten, and press. Sew a decorative stitch along the collar ends and the outer edge of the collar. Sew the parts of the stand collar, inserting the collar between the pieces. Trim the seam allowances, turn right side out, and press.
8. Sew the upper stand collar into the neckline of the garment. Fold the seam allowance of the lower stand collar onto the wrong side and stitch-in-the-ditch along the seam of the upper stand collar.

9. Cut (or take ready-made) bias tape; its width should equal 4 cm, and the length should equal the length of the armhole + 6 cm. Fold the bias tape in half lengthwise, right side out, and press. Pin the bias tape onto the armhole edge from the right side, leaving loose ends, and sew. Fold the bias tape onto the wrong side, clip into the seam allowances, and topstitch onto the main piece along the seam. Press the seam.
10. Sew side seams, press towards the back, and serge.
11. Fold the lower placket in half lengthwise, right sides together, and sew the side edges. Start and stop stitching exactly at the marked seam line of the plackets. Turn the piece right side out and press. Sew the outer side of the placket to the hem of the garment, turn the seam allowance of the inner side of the placket under, and stitch-in-the-ditch along the seam of the outer placket.
12. Fold the tab in half lengthwise, right sides together, and sew the longer and one shorter edge. Trim the seam allowances, turn right side out, and press. Sew decorative stitch lines along the finished sides. Fold inside the unsewn edge and topstitch the tab onto the lower placket according to the markings.
13. Install push buttons according to the markings.

Congratulations, your vest is ready! :)