

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2736 Blouse with drawstring casing and round collar

Recommendations on fabric: natural/mixed fabrics suitable for blouses approx. 1.2 m (size 32-44), approx. 1.5 m (size 46-54) with a fabric width of 150 cm.

You will also need: fusible interfacing, 5 buttons.



CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 2 cm; other seams – 1 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Collar – cut 2
5. Casing – cut 1 on fold

Fusible interfacing:

1. Collar – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Also, apply fusible interfacing to the one-piece placket on the front.
2. Sew front darts, pressing the bulk towards the top.
3. Fold the one-piece placket onto the wrong side and press according to the marked line on the center front facings. Fold the longer seam allowance of the one-piece placket inside and topstitch the placket onto the front.
4. Sew shoulder and side seams, press towards the back, and serge.
5. Pin the upper collar to the lower collar, right sides together. Sew the ends of the collar and collar fall. Start and stop sewing exactly at the marked seam line. Trim the seam allowances, turn the collar right side out, straighten, and press. Sew the lower collar into the neckline, fold under the raw edge of the upper collar, and stitch in the ditch.
6. Serge the seam allowances of the shorter edges of the casing, press them onto the wrong side, and topstitch. Fold the seam allowances of the longer edges of the casing onto the wrong side and press. Pin the casing onto the right side of the garment according to the markings and topstitch.
7. Sew the sleeve seam, press towards the back, and serge. Sew the sleeves into the armholes, serge, and press.
8. Fold the hem of the garment and the hem of the sleeve inside at 1 cm, then again at 1 cm, and topstitch.
9. Make buttonholes on the right front and sew on buttons on the left one.
10. Cut a bias tape for the tie from the main fabric; its width should equal 4 cm, and its length should equal the waist girth + 50 cm. Fold the tape in half lengthwise and press. Press the outer seam allowances towards the center and topstitch along the edge. Thread the tie into the casing.

Congratulations, your blouse is ready! :)