

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 2737 Blouse with front flounce.

Recommendations on fabric: natural/mixed fabrics suitable for blouses approx. 1.2 m (sizes 32-44), approx. 1.5 m (sizes 46-54) with a fabric width of 150 cm.

You will also need: fusible interfacing, 5 buttons.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: Seam allowance for hem of garment – 2 cm, other seams – 1 cm.

### Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Cap of sleeve – cut 4
4. Right collar – cut 2
5. Left collar – cut 2
6. Center front facing – cut 2
7. Back neck facing – cut 1



Fusible interfacing:

1. Right collar – cut 1
2. Left collar – cut 1
3. Center front facing – cut 2
4. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew front darts and press the bulk towards the top.
3. Sew shoulder seams, press towards the back, and serge.
4. Sew the central edges of the left collar and right collar. Press the seam apart. Pin the upper collar to the lower collar, right sides together, and sew the collar edge and the end of the left side. Trim seam allowances, turn the collar right side out, straighten, and press. Make a pleat at the neckline edge on the right side according to the technical drawing and baste the pleat to prevent shifting. Sew the collar into the neckline and attach the right long side to the front center edge.
5. Sew the shoulder seams of the back neckline facing and central front facing, then press the seam apart. Serge the outer edge. Pin the facing and the center front facing onto the right side of the garment and sew the neckline and center front facings. Clip the seam allowances, trim away corners, fold the facings and center front facing onto the wrong side, and press. Sew the facing to the shoulder seams by hand.
6. Pin the wing sleeves together, right sides together, and sew the outer edges. Trim seam allowances, turn right side out, and press. Sew the wing sleeves into the armholes, then serge and press.
7. Sew the side seams, press towards the back, and serge.
8. Cut or use ready-made bias tape; its width should equal 4 cm and its length should equal the length of the lower armhole plus 4 cm. Fold the bias tape in half lengthwise, right side out, and press. Pin the bias tape to the armhole edge from the right side and sew. Clip into seam allowances, fold the bias tape onto the wrong side, and topstitch onto the main piece along the seam. Press the seam.
9. Turn the hem under inside at 1 cm, then again at 1 cm, and topstitch.

10. Make buttonholes on the right front, folding the collar away, and sew on buttons on the left side.

Congratulations, your blouse is ready! :)