

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2743 Blouse with asymmetric closure and collar

Recommendations on fabric: natural/mixed fabrics suitable for dresses or blouses approx. 1.5 m (size 32-42), approx. 2 m (size 44-54) with a fabric width of 150 cm.



You will also need: fusible interfacing, 2 buttons.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: all seams 1 cm, seam allowance for hem of garment and hem of sleeve – 2.0 cm.

Main fabric:

1. Back - cut 2
2. Right front - cut 1
3. Left front – cut 1
4. Sleeve - cut 2
5. Collar – cut 2
6. Back neck facing – cut 1
7. Left center front facing – cut 1

Fusible interfacing:

1. Collar – cut 1
2. Back neck facing – cut 1
3. Left center front facing – cut 1

INSTRUCTIONS:

1. Sew darts on the back. Press the bulk towards the center. Sew the center back seam, serge the seam allowances, and press towards the left.
2. Sew darts on the front, pressing the bulk towards the top.
3. Serge the outer edge of the right front. Snip into the seam allowance of the neckline near the mark. Fold the one-piece placket to the right side and sew the upper corner. Trim the seam allowances, turn right side out, and press. Sew a decorative/fixing stitch along the center front edge.
4. Pin the collars with right sides together and sew the outer edge and lower corner of the collar. Start and stop stitching exactly at the marked line of the collar seam. Clip the seam allowances, trim the corner, turn the collar right side out, and press. Sew the outer collar into the neckline of the front. Fold the seam allowance of the inner collar inside and topstitch into the seam of the outer collar. Sew the seam allowances of the collar and the shoulder edge together by hand.
5. Serge the outer edge of the left center front facing. Pin the center front facing to the right side of the left front, then sew the neckline and center front edge up to the notch. Clip into the seam allowance near the notch. Turn pieces right side out and press. Sew the left front to the left center front facing from the mark down to the hem, then serge the seam allowances. Sew a decorative/fixing stitch along the marked line.
6. Serge the outer edge of the back neckline facing. Pin the back facing to the back and sew the neckline. Start and stop stitching exactly at the marked line of the shoulder edge. Clip the seam allowances, fold the facing to the wrong side, and press.
7. Pin the right front onto the left front and sew from the right side along the decorative stitch line on the right front. Sew a horizontal fixing double stitch.
8. Sew shoulder seams, inserting the fronts between the back and back facing. Serge and press towards the back.
9. Sew side seams, press towards the back, and serge.

10. Sew the sleeve seam, press towards the back, and serge. Sew the sleeves into the armholes, serge, and press.

11. Fold the lower edge of the garment and the lower edge of the sleeve onto the wrong side twice by 1 cm and topstitch.

12. Make buttonholes and sew buttons on the fronts.

Congratulations, your blouse is ready! :)