

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

2837 Shirt with Asymmetrical Closure

Recommendations on fabric: natural/mixed fabrics suitable for shirts.

You will also need: fusible interfacing; 5 buttons.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: Seam allowance for hem of back – 2 cm; other seams – 1 cm.

Main fabric:

1. Back – cut 1 on fold
2. Front right – cut 1
3. Front left – cut 1
4. Center Front Edge right – cut 2
5. Center Front Edge left – cut 2
6. Sleeve – cut 2
7. Collar – cut 2
8. Cuff – cut 2

Fusible interfacing:

1. Collar – cut 1
2. Cuff – cut 2
3. Center Front Edge right – cut 1
4. Center Front Edge left – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Pin the right center front pieces together, right sides together, and sew along the outer edges. Clip the seam allowances and trim the corners. Turn the pieces right side out and press. Clip into the neckline seam allowance near the marking. Topstitch decoratively 0.5 cm from the seam.
3. Sew the right center front edge to the right front. Serge the seam allowances and press them toward the main piece. Topstitch decoratively 0.5 cm from the seam.
4. Sew the left front in the same manner.
5. Sew the shoulder seams, press toward the back, and serge.
6. Pin the upper collar to the lower collar, right sides together, and sew the collar ends and the collar fall, starting and stopping exactly at the marked seam line between the collar and the garment. Trim the seam allowances, turn the collar right side out, shape, and press. Topstitch decoratively along the collar ends and the outer edge. Press the finished collar. Sew the upper collar to the neckline. Fold under the seam allowance of the lower collar and stitch in the ditch along the upper collar seam.
7. Sew the sleeves into the armholes, serge, and press.
8. Sew the side seams and sleeve seams (the back is longer than the front by the width of the lower seam allowance). Serge the seams and press toward the back.
9. Fold the cuffs in half lengthwise, right sides together, and sew the side edges. Turn right side out and press. Clip the sleeve hem seam allowance near the notch. Sew the cuff to the lower edge of the sleeve, serge, and press upward. Topstitch decoratively around all cuff edges.
10. Serge the lower seam allowance on the back, turn it to the inside, and topstitch.
11. Make the buttonholes and sew on the buttons.

Congratulations – your shirt are finished! :)