

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 4083 Coat with shaped collar

Recommendations on fabric: lightweight fabrics suitable for coats of natural or mixed fibers

You will also need: soft cloth fusible interfacing; 5 buttons; lining; shoulder pads; sleeve heads

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



### Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center right front – cut 1
5. Center left front – cut 1
6. Right front band facing – cut 1
7. Left front band facing – cut 1
8. Stand-up collar – cut 1
9. Upper sleeve – cut 2

10. Lower sleeve – cut 2
11. Back neck facing – cut 1

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Pocket bag – cut 4

ATTENTION: back and front lining pieces are cut excluding the width of back neck facing and front band facings.

Fusible interfacing:

1. Right front band facing – cut 1
2. Left front band facing – cut 1
3. Stand-up collar – cut 1
4. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply interfacing to front band facings, back neck facing, stand-up collar and seam allowances on hem of the garment and of sleeve. Interfacing laps over hem line at 1 cm.
2. Pin front band facings to fronts, right sides together, sew center front edge and lapel. Sew from hem line up to marker «O». Sew lower edge of facing to front exactly on marked line of hem, leaving 1.5 cm to inner edge of facing. Trim corner, and under-stitch. Turn facings onto right side, straighten seams.
3. Sew center back seam, press seam apart and serge up to waist. Sew side backs to center back and side fronts to center fronts. Press seam allowances apart and serge up to waist.
4. Sew outer stand-up collar to back neckline, press seam apart. Sew inner collar to back neck facing. Press seam allowances apart.
5. Sew shoulder seams of back and front, continuing to stitch stand-up collar with facing to main garment. Press seam allowances towards back. Fold stand-up collar in half and fix together at connection allowances.

6. Sew pocket bags to side seam allowances. Sew side seams, stitching pocket bags at the same time. Trim seams near pocket opening on side back. Press bags towards center of front, press side seam towards back and serge up to waist.
  7. Sew and press apart elbow sleeve seam. Press hem of sleeve. Unfold hem and sew, press front sleeve seam apart.
  8. Make a gathering stitch along sleeve cap for ease. Sew sleeves into armholes matching notches and adjusting ease. Sew in shoulder pads and sleeve heads.
  9. Sew lining same as main fabric. Serge seam allowances of side and relieve seams from hem up to waist. Turn seam allowance of lower edge of lining twice at 1.5 cm and topstitch.
  10. Serge and turn up seam allowance of hem of the garment. Sew with invisible stitches. Sew lining to inner facing edges. Start and finish the stitch on half of hem turnup width of the main garment. Snip seam allowance on inner edge of front band facing near the beginning of lining connection. Turn seam allowance of front band facing inwards from hem line up to slash and sew with invisible stitches. Serge seam of lining and press towards side of lining.
  11. Sew lining to lower edge of sleeves. Press seam onto lining.
  12. Make buttonholes on right front, sew buttons on left.
- Congratulations, your coat is ready! :)