

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

**Important!** Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

## 4177 Top with Asymmetric Peplum

Recommendations on fabric: blouse fabrics from natural or mixed fibers.

You will also need: 1 blind zipper, bias tape.

### CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: sleeve hem – 2 cm, garment hem – 1.5 cm, other seams – 1.0 cm.

### Main fabric:

1. Center front – cut 1 on fold
2. Center back – cut 2
3. Sleeve – cut 2
4. Side front – cut 2
5. Side back – cut 2
6. Peplum – cut 1 on fold

### INSTRUCTIONS:



1. Sew side fronts to front and side backs to back. Serge seams and press toward the center of front and back accordingly.
2. Sew shoulder seams. Serge and press seams toward back.
3. Serge sleeve hems, fold to the inside, and topstitch. Sew sleeves into armholes, matching notches. Fold bias tape in half lengthwise, wrong sides together, and press. Sew the bias tape to the armhole edge from the right side. Turn the bias tape to the wrong side, clip curves, press seam, and topstitch from the right side. This finishes the lower half of the armhole under the sleeve. (You can do this after sewing the side seams for a neater finish.)
4. Sew side seams. Serge and press seams toward back.
5. Stitch peplum to lower edge of garment. Serge and press seam upward. Serge center back edges separately. Sew back sections together from the mark for the bottom of the zipper on the peplum to the garment's lower edge. Press seam open, including the zipper opening. Insert zipper.
6. Cut bias tape the length of the neckline plus a small allowance to encase the zipper tape edge. Fold bias tape in half lengthwise, wrong sides together, and press. Sew the bias tape to the neckline edge from the right side, turn to the wrong side, press, and topstitch from the right side.
7. Press peplum hem to the wrong side, serge, and topstitch.

Congratulations – your top are finished! :)