

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4211 Coat with decorative collar

Recommendations on fabric: fabric suitable for coats.

You will also need: interfacing; lining; 5 buttons; shoulder pads, sleeve heads.

CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

1. Central back – 2 details
2. Side back – 2 details
3. Central front – 2 details
4. Side front – 2 details
5. Upper sleeve part – 2 details
6. Lower sleeve part – 2 details
7. Back neckline facing – 1 detail
8. Button stand – 2 details
9. Collar – 2 details
10. Belt loop – 1 detail
11. Belt – 1 detail



Lining:

1. Central back – 2 details
2. Side back – 2 details
3. Side front – 2 details
4. Central front – 2 details
5. Upper sleeve part – 2 details
6. Lower sleeve part – 2 details

Interfacing: central front, button stand, back neckline facing, hem of sleeve, upper collar.

INSTRUCTIONS:

1. Apply interfacing to details. Apply interfacing to back neckline.
2. Sew darts on back. Press depths towards center. Sew princess edges on back. Press apart the seam. Sew center edge of back. Press seam allowance apart.
3. Sew princess edges on front. Press apart the seam.
4. Sew and press apart side and shoulder edges of coat.
5. Fold upper collar with lower and overstay sections: from mark «O» up to opposite corner of collar; between marks «arrow». Slash seam allowances, trim in corners. Turn collar out, straighten and press.
6. Sew and press apart shoulder edges of back neckline facing and button stand.
7. Sew and press apart elbow sleeve seam and vent corners on lower and upper parts of sleeve. Press apart elbow sleeve seam, make a slash and press the vent. Put cross staystitch on vent of sleeve. Press hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes according to notches, easing in on rounded part. Sew in shoulder pads, sew sleeve heads.
8. Put button stand onto right side of front right side downwards, and overstay section on right front between marks «o». Slash seam allowances.
9. Sew in lower collar. Start stitch on left front from mark «o» up to mark «o» on right front. Second stitch – from mark «o» up to edge of button stand. The same way sew upper collar into the neckline of button stands and facing. Press apart collar connecting seams. Overstay front bands: right band – together with edge of collar, on left band –

overstitching the ledge.

10. Fold belt loop detail in half lengthwise and sew edges. Turn right side out, press and cut needed amount of belt loops. On front stitch belt loops onto side parts, and on back stitch them onto center seam and at princess seams level.

11. On lining details sew seams and sew in sleeves, leaving a slit open in front right seam of sleeve. Stitch lining to button stands and facing.

12. Press hem of coat. Stitch lining to hem of coat. Turn coat out through the slit in sleeve. Sew slit in sleeve closed.

13. Fold belt in half lengthwise right sides together and overstretch, leaving a slit open. Turn belt out through the slit and sew it closed. Put decorative stitch along contour at 0.5 cm off the edge.

14. Serge buttonholes on right front, sew buttons on left front.

15. Sew button on vent.

Congratulations, your coat is ready! :)