

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4583 Short jacket in coat fabric

Recommendations on fabric: Natural/mixed double-sided, non-fraying fabric suitable for coats.

You will also need: lining, 4 snaps, fusible interfacing.



CUTTING:

The word, "beam" used on some patterns means "straight of grain". Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Seam allowances: on neckline, hems, front facing edge - 0.5 cm, all other seams - 1 cm.

Main fabric:

1. Back neck facing - cut 1
2. Front facing – cut 2
3. Back – cut 1 on fold
4. Front – cut 2
5. Lower placket - cut 1 on fold
6. Welt - cut 2
7. Sleeve – cut 2

Fusible interfacing:

1. Back neck facing – cut 1

2. Front facing – cut 2
3. Lower placket - cut 1
4. Welt - cut 2

Lining:

1. Small pocket bag – cut 2
2. Large pocket bag – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing to listed pieces.
2. Fold the welt in half and press. Mark pocket location on fronts. Mark supportive lines on the welt. Mark supportive lines parallel to pocket opening. Attach the welt pieces to the marked in the front lines and sew. End stitch at parallel lines of pocket marking. Stitches must be parallel from the wrong side. Cut pocket opening. Make cross cuts at 1 - 1.5 cm from pocket end. Turn welt to wrong side through the opening, straighten edges. Sew pocket bags. Fasten pocket ends from wrong side with double back stitch on corner section and continuing stitch on pocket bags edges.
3. Sew shoulder seams. Press open.
4. Sew sleeves into an open armhole. Press seams open. Press sleeve cuff to right side and topstitch. Sew the side and sleeve seam. Press open.
5. Sew shoulder seams of front band facing and facing. Press seams open. Sew lower placket to front facing. Place front facing with placket and neck facing on front, right sides together (if you are using double sided fabric, you may choose to use the contrasting side), and sew with 0.5 cm seam.
6. Install snaps.

Congratulations, your jacket is ready! :)