

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: 1 cm on all seams; hem guidelines are printed on pattern.

Important! Please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need.

Don't forget to take into account pieces to be duplicated or cut on a fold. When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

4711 Blouse with Decorative V-Neckline

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.



Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 1.2 cm.

Main fabric:

1. Back facing – cut 2
2. Back – cut 1 on fold
3. Front – cut 1
4. Collar – cut 4
5. Lapel – cut 4
6. Sleeve – cut 2

Fusible interfacing:

1. Back facing – cut 1
2. Collar – cut 2
3. Lapel – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew outer back facing to back; press seam allowances towards facing.
3. Pin collar, right sides together, and sew ends and outer edge. Clip into seam allowances near notches, turn collar right side out, and press. Pin lapels together, right sides facing, place the collar in between, and sew the collar and lapel according to markings, sewing the outer edge of the lapel at the same time. Turn the lapel right side out, straighten, and press.
4. Pin the right lapel over the left and baste together along the lower edge. Sew the collar with lapel into the front neckline, serge, and press.
5. Serge the inner edge of the inner back facing. Pin the facing onto the back and serge the neckline (start and stop stitching exactly at the marked line of the shoulder seam). Clip into curves. Insert the shoulder edge of the front between the inner facing and back, then sew. Serge, press towards the back, and turn the garment right side out. Stitch-in-the-ditch the back facing.
6. Sew in the sleeve, press seam allowances towards the sleeve, and serge.
7. Sew the side seam, and continue sewing the sleeve seam. Serge and press.
8. Serge the hem of the garment and sleeves, press onto the wrong side, and topstitch.

Congratulations, your blouse is ready! :)